











## Compatibility table




















# Emergency phone charger (SCE2110)

Tip	Product	Brand	Model
		Motorola	A732, A780, A910, E1070, E680, E770v, KRZR KI, SLVR L2, SLVR L6, SLVR L7, MPx200, RIZR Z3, ROKR E2, PEBL U6, VI91, VI95, V235, V360, VI075, RAZR V3, RAZR VR 3i, RAZR V3x.
		Nokia (small)	3250, 6070, 6101, 6103, 6111, 6125, 6131, 6136, 6233, 6270, 6280, 7360, 7370, E61, N70, N71, N72, N73, N80, N90, N91, N92, N93 and compatible telephones.
		Nokia	1100, 1101, 1110, 1600, 2300, 2600, 2650, 2652, 3100, 3120, 3220, 3230, 3300, 3660, 5100, 5240, 5140i, 6020, 6021, 6030, 6060, 6100, 6170, 6230, 6230i, 6260, 6310i, 6600, 6610i, 6670, 6680, 6681, 6810, 6820, 6822, 7260, 7270, 7280, 7360, 7380, 7610, 7710, 800, 9210i, 9300, 9300i, 9500, E60, E70, N-gage (TM) QD game deck and compatible telephones.
		Samsung	SGH-D520, SGH-D800, SGH-D80, SGH-D820, SGH-D900, SGH-ES540, SGH-E550, SGH-E780, SGH-E870, SGH-P300, SGHT509, SGH-T809, SGH-V804, SGH-Z150, SGHZ510, SGH-Z540 and compatible telephones.
		Sony Ericsson	D750i, J100i, J230i, K310i, K610i, K610iM, K750i, K800i, M600i, P990i, V630i, W300i, W600i, W710i, W800i, W810i, W850i, W880i, W900i, W950i, Z310i, Z520i, Z530i, Z550i, Z610i.

## Compatibility table

(SCE4420, SCE4430, SCE7640, SCM4380, SCM4480 and SCM7880)






Tip	Product	Brand	Model
		Motorola	Alcatel OT-E801, OT-S853. Motorola A732, A780, A910, E1070, E680, E770v, KRZR, KI, SLVR L2, SLVR L6, SLVR L7, MPx200, RIZR Z3, ROKR, E2, PEBL U6, V191, V195, V235, V360, V1075, RAZR V3, RAZR VR 3i, RAZR V3x.
		RIM	BlackBerry
			Works with devices charged via mini USB
		Jabra Southwing	BT6205 SA 505
		Motorola	E398/ROKR E1, V500/V600 series, E550, V300, V80, T720i, V975/V980, C975/C980, A1000, E1000.
		Nokia (small)	3250, 6070, 6101, 6103, 6111, 6125, 6131, 6136, 6233, 6270, 6280, 7360, 7370, E61, N70, N71, N72, N73, N80, N90, N91, N92, N93 and compatible telephones.
		Nokia	1100, 1101, 1110, 1600, 2300, 2600, 2650, 2652, 3100, 3120, 3220, 3230, 3300, 3660, 5100, 5240, 5140i, 6020, 6021, 6030, 6060, 6100, 6170, 6230, 6230i, 6260, 6310i, 6600, 6610i, 6670, 6680, 6681, 6810, 6820, 6822, 7260, 7270, 7280, 7360, 7380, 7610, 7710, 8800, 9210i, 9300, 9300i, 9500, E60, E70, N-gage (TM) QD game deck and compatible telephones.
		Samsung	SGH-D520, SGH-D800, SGH-D80, SGH-D820, SGH-D900, SGH-ES540, SGH-E550, SGH-E780, SGH-E870, SGH-P300, SGHT509, SGH-T809, SGH-V804, SGH-Z150, SGHZ510, SGH-Z540 and compatible telephones.
		Sony Ericsson	D750i, J100i, J230i, K310i, K610i, K610iM, K750i, K800i, M600i, P990i, V630i, W300i, W600i, W710i, W800i, W810i, W850i, W880i, W900i, W950i, Z310i, Z520i, Z530i, Z550i, Z610i.
		Nintendo DS	

# Compatibility table



## Rechargeable power pack for laptops (SCE7640)

Tip	Laptop	Model
	HP	<b>Armada</b> I10, 300, E500 series, E700 series, M300 series, M700 series, V300 series, 600 series, 800 series, m-series, EVQ N40, NI10, NI50, NI60, NI80, N200, N200C, N400C, N410C, N600C, N610C, N800C, N800V Series, N800W, NI000C, NI000V, NI015V, NI020V, NI050V. <b>Prosignia</b> I50, I60, I70, I90. <b>Business Notebook</b> nc4000 series, nc4010 series, nc6000 series, nc8000 series, nw8000 series, nx7000 series, nx5000, series, nx7000 series, nx7010 series, nv7100 series, nx9000 series, nx9040v.
	Asus	3A1000 series. <b>AtrBook</b> L7336, B1000 series, F7000. <b>Grandio</b> F7400, F7400, L1000 B series, L2000 B series, 2000 E series, L3000 C series, L3000 S series, L7000, L7000C, L7200, L7233, L7300, L8400, M1000 Series, m2000 series, m2 series, mp8xxxseries, s000 series t4700CS, T7200, T9000 series.
	Acer	<b>Travelmate</b> 200, 201, 202, 203, 204, 205, 210, 212, 213, 220, 222, 260, 261, 310-314, 330, 332, 333, 340-347, 350-354, 361-364, 501-517, 520, 521, 524, 525, 527-529, 534, 600, 602-604, 610-614, 620-623, 630-633, 710, 720-723, 730, 732, 734-744.
	Acer	<b>TI Extensa</b> 501, 502, 503, 600 series, 700 series, 712 series.
	Toshiba	<b>Satellite</b> T1850, T1900, T1910, T1950, T1960, T2400, T3400, T3600, T4500, T4600, T4700, T4700C, T4700CS, T4700CT, T4700, T4800, T4800CT, T4850CT, T4900, T4900CT, T4950CT.
	HP	<b>Armada</b> I100, I120, I125, I130, 4100, 4110, 4110D, 4110T, 4120, 4120T, 4124D, 4125D, 4130, 4130T, 4131, 4131T, 4150T, 4160, 4160T, 4210T, 4220T. <b>Contura</b> 3/20, 3/25, 3/25c, 4/20, 4/25, 4/25c, 4/25cx. <b>ThinkPad I Series</b> I410, I411, I441, I450, I451, I472 series.
	IBM	<b>ThinkPad</b> 730t, 350 series, 500, 510 series.
	NEC	<b>Ready</b> 220t, 330t, 340t, 360t.
	Sony	<b>Vaio</b> GR, SR, SRX, VX series, pcg-505, pcg-505ex, pcg-505f, picturebook, pcg-clx, 505, pcg-505fx, pcg-505g, pcg, 505gx, pcg-505ls, pcg-505tR, pcg-505ts, pcg-505tx, pcg-505x, pcg-xg, 808, 812, 818, 838, pcg-r600, qr series, pcg-430, thru 490, pcg-431, pcg-450, pcf-461, pcg-480, pcg-481, pcg-490, pcg-491, pcg-700, pcg-705c, pcg-707c, pcg-747, pcg-717c, pcg-719c, pcg-731, pcg-737, pcg-745, pcg-747, pcg-705 thru 748c, xg series, 580, 800, pcg-900, Vaio pcg-955a, pcg-z505, pcg-z600, pcg-r600, QR Series, PCG-735.
	Dell	LX450, XP4100, XP4100C, XP4100CX, XP4100T, XP450C, XP475C, XP475D.
	Fujitsu	Series B.C.E.FMV, CX, L, I, S. <b>Lifebook</b> 270DX, 280DX, 400, 420, 420DX, 435DX, 470, 520, 520D, 520T, 530, 530T, 531T, 531TX, 535T, 535TX, 555TX, 565ITX, 585TX, 635, 635T, 635TX, 655, 655TX, 656TX, 675TX, 690TX, 735CDT, 735TX, 755TX, 756DX, 765TX, 770TX, 785TaX, 790TX, 985TX, 990TX, 990TX2. <b>Lifebook, Milan, Montego Fujitsu Lifestyle, Pen Centra</b> 200, <b>Stylistic</b> 3400, 2300, I200, <b>Point</b> 510, <b>Stylus</b> 3400 tablet.

Tip		Laptop	Model
	AN-A07	Toshiba	<b>Satellite</b> T200, T220, T225, T305, T315, T320, T325, T330, T335, T440, T460, T470, T490, TI555, TI800, T2000, T2100, T2140, T2180, T2210, T2280, T2500, T2590, T2600, T2615, T2655, T2675, T2700, T2715, T2800, T2805, T4000, T4010, T4020, T4030, T4060, T4080, T4100, T4200, T4280, T4300, T4600, I800-s203, I800-s253, 2250xcds, 2250cdt. <b>Satellite Pro</b> 400, 405, 410, 415, 420, 425, 430, 435, 440, 445, 460, 465, 470, 480, 490, 490x, cdx, cds. <b>Tecra</b> 500, 505, 510 including, cdt m1, m2, s1730x, 520, 530, 550, 710, 720, 730, 730x, 740, 750, 780, 8000, 8100, 8200, 9000, 4090xdvd, 2546CDS.
		Sony	<b>Libretto</b> 300, 320, 610, 620, 650, 660, 3400, 3600, 7000, 7010, 7020, 7030, 7140, 7200, m200 tablet. <b>Protege</b> 20ct, 30ct, 50ct, 60ct, 70ct.
		NEC	<b>Versa</b> LX series, SX series.
	AN-A08	Dell	<b>Precision</b> M20, M60, M70 workstation. <b>Latitude</b> D400, D410, D500, D505, D600, D610, D800, D810, X300. <b>Inspiron</b> I150, 6000, 8500, 8600, 9200, 9300, 300m, 500m, 600m, 700m.
	Cable	HP	<b>EVQ</b> NI05, NI15, NI60, NI80. <b>Presario</b> 700 series, 1000 series, 1200 series, 1245 series, 12xl series, 14xl series, 1700 series, 17xl series, 700t, 1700xl, 573, 1710SB, I800 series, I8xl series, I800 XL, 2100 series, 2500 series, 2700 series, 2700t, 800, 800xl. <b>Pavillion</b> ZT1131, ZT1132, T1135, ZT1141, ZT1142, ZT1145, ZT1151, ZT1152, ZT1155, ZT1161, ZT1162, ZT1171, ZT1172, ZT1175, ZT1180, ZT1181, ZT1182, ZT1185, ZT1190, ZT1192, 5200, series, 5400 series, pavilion ZE, ZT, ZU series, XH455, XH485, XH535, XH545, XH555, XH575, XH675, XU155, XZ185, XZ275, ZE1110, ZT1114, ZT1120, ZT1121, ZT1125, ZT1130, n3000 series, n3200 series, n3300 series, n5000 series, n5300, series, n5400 series, n5500 series, dv1000 series, dv4900 series, ZF3000 series, ze4000series, ze5000 series. <b>Omnibook</b> 2000, 2100, 2103, 2105, 2106, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 3000, 3000CTX, 3101, 3250, 4000, 4000c, 4000ct, 4000e, 4000m, 4100, 4150, 4150B, 6000 Series, 6100 series, 7000 series, 6050, 6020, VT6200, XT1000, XT15 2000, 7100 Series, 7103, 7150, series, xE series, xe2 series, xe3 series, 900 series, N3100, N3110, N3150, N3200, N3250, N3270, N3290, N3295, N3300, N3390, N3400, N3402, N3401, N3438, N3478, N3490, N5000, N5100, N5125, N1340, N5150, N5170, N5190, N9195, N5200, N5210, N5240, N5250, N5270, N5290, N5295, N5300, N5310, N5311, N5340, N5421, N5422, N5425, N5430, N5435, N5440, N5441, N5442, N5444, N5445, N5450, N5452, N5454, N5455, N5461, N5462, N5470, N5472, N5474, N5475, N5481, N5482, N5484, N5490, N5491, N5495, N5511, N5584, N6195, N6395, N6396, N6397, N6398, N6399, N6400, N6401, N6403, N6404, N6490. <b>Contura</b> 386/486 series, 400c, 400cx, 410, 410cx, 420c, 420cx, 430c, 430cx.
		IBM	<b>ThinkPad</b> 235, 240, 290, 310, 340, 345, 365, 380, 385, 390, 535, 560, 570, 600, 701, 770, 2621-xxx, 1161-xxx, 600x, series, 2645, 2611A, T, X&R Series. <b>Transnote</b> T21.
		Asus	<b>TI Extensa</b> 390, 390c, 391, 392, 393, 394, 395, 512, 513, 514, 515, 516, 617, 610, 610CD, 610CDT, 616 series, 620 series, 690 series, 900 series.
		Dell	<b>Inspiron</b> 433M, 43MC, 433MCX, 450MC, 450MCX, 475C, 475D, 475MC, LX, LXX, 4100/T, 3000, 3200, 3500, 7000.