



Philips
PC control pad

wireless

SGC2910

Play wire-free across the room

Play your best, uninhibited by restraining cables. PC game controller replaces a keyboard for quicker response and more comfortable play. Profiler software emulates keyboard commands for better game play.

Play wire-free

- Wireless technology

Optimize your PC game play

- Profiler software
- Built-in dual vibration motors
- Retractable USB cable
- 4 shoulder triggers
- 4 digital fire buttons
- 8-way directional control pad
- Illuminated turbo fire button
- Rubber tactile grips
- Fully pressure sensitive analog sticks and directional pad

PHILIPS

PC control pad
wireless

Specifications

Packaging

- EAN/UPC/GTIN: 6 09585 12820 0
- Quantity: 1
- Gross Weight: .548 kg
- Tare Weight: .148 kg
- Net Weight: .400 kg
- Length: 22.5 cm
- Width: 5.6 cm
- Height: 21.2 cm

Inner Carton

- EAN/UPC/GTIN: 1 06 09585 12820 7
- Quantity: 4
- Gross Weight: 2.19 kg
- Tare Weight: .34 kg

- Net Weight: 1.85 kg
- Length (cm): 47.7 cm
- Width (cm): 21 cm
- Height (cm): 17.8 cm

Outer Carton

- EAN/UPC/GTIN: 2 06 09585 12820 4
- Quantity: 16
- Gross Weight: 8.78 kg
- Tare Weight: 1.18 kg
- Net Weight: 7.6 kg
- Length (cm): 49.5 cm
- Width (cm): 36.8 cm
- Height (cm): 44.1 cm

SGC2910/27

Highlights

Wireless technology

Infrared technology allows you to play wire-free up to 100 ft from the console.

Profiler software

Built-in software emulates keyboard commands for better playing of the game.

Built-in dual vibration motors

Two internal motors with unbalanced weights provide vibration when activated by the game for total immersion in the game.

Retractable USB cable

6 ft retractable USB cable easily connects to PC or laptop to eliminate messy cable clutter and provide convenient storage.

4 shoulder triggers

These interactive control buttons are located on the front of the controller and control certain functions of the game.

4 digital fire buttons

These digital control buttons are located on the face of the controller and control certain functions of the game.

8-way directional control pad

Directional pad that represents up, down, left, right and four diagonals, controlling certain directional functions of the game.

Illuminated turbo fire button

Automatic action button functions in a repeating action mode to allow quicker reactions to game events.

Rubber tactile grips

Molded rubber grips on handle enhance comfort and dexterity during game play.

Fully pressure sensitive

Fully pressure sensitive analog sticks and directional pad enables operation of software with pressure-sensitive functions.



Issue date 2014-03-18

Version: 2.2.6

12 NC: 8670 000 27955
UPC: 6 09585 12820 0

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com