

Philips
PC control pad

wireless

SGE2910BD



Play wire-free across the room

Play your best, uninhibited by restraining cables. PC game controller replaces a keyboard for quicker response and more comfortable play. Profiler software emulates keyboard commands for better game play.

Play wire-free

- Wireless technology

Optimize your PC game play

- Fully pressure sensitive analog sticks and directional pad
- Rubber tactile grips
- Profiler software
- Built-in dual vibration motors
- Retractable USB cable
- 4 shoulder triggers
- 4 digital fire buttons
- 8-way directional control pad
- Illuminated turbo fire button

PHILIPS

sense and simplicity

PC control pad
wireless

Specifications

Packaging

- EAN/UPC/GTIN: 6 09585 11967 3
- Quantity: 1
- Gross Weight: .548 kg
- Tare Weight: .148 kg
- Net Weight: .400 kg
- Length: 22.5 cm
- Width: 5.6 cm
- Height: 21.2 cm

Outer Carton

- EAN/UPC/GTIN: 1 06 09585 11967 0
- Quantity: 4
- Gross Weight: 2.190 kg
- Tare Weight: .340 kg
- Net Weight: 1.85 kg
- Length (cm): 47.7 cm
- Width (cm): 21 cm
- Height (cm): 17.8 cm

SGE2910BD/37

Product highlights

Fully pressure sensitive

Fully pressure sensitive analog sticks and directional pad enables operation of software with pressure-sensitive functions.

Rubber tactile grips

Molded rubber grips on handle enhance comfort and dexterity during game play.

Wireless technology

Infrared technology allows you to play wire-free up to 100 ft from the console.

Profiler software

Built-in software emulates keyboard commands for better playing of the game.

Built-in dual vibration motors

Two internal motors with unbalanced weights provide vibration when activated by the game for total immersion in the game.

Retractable USB cable

6 ft retractable USB cable easily connects to PC or laptop to eliminate messy cable clutter and provide convenient storage.

4 shoulder triggers

These interactive control buttons are located on the front of the controller and control certain functions of the game.

4 digital fire buttons

These digital control buttons are located on the face of the controller and control certain functions of the game.

8-way directional control pad

Directional pad that represents up, down, left, right and four diagonals, controlling certain directional functions of the game.

Illuminated turbo fire button

Automatic action button functions in a repeating action mode to allow quicker reactions to game events.



Issue date 2008-11-15

Version: 1.3.8

12 NC: 9082 100 09704
UPC: 6 09585 11967 3

© 2008 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com