


Firmware Upgrade

Upgrade Benefits: Improve the White Balance setting for your webcam.

How do I upgrade the firmware of my webcam?

Following the below procedure:

1. Connect your webcam to your PC.
2. Click on the “Download” on this page to download the firmware on your PC.
3. Double click the downloaded file.
4. Click on the “**Burn**” on the upgrade screen. **Note: During the update DO NOT disconnect your webcam from your PC.**



5. Wait until the update is fully finished → the full progress bar, and messages “**OK**” and “**Finish successfully!**” will be shown.

