



Philips
DVD laser lens cleaner

Brush system
Twelve

SVC2522W



Clean and protect your DVD player

Regular cleaning of your DVD player's lens ensures optimum performance of your equipment. It is important to keep a DVD player optical laser lens clean and dust free. This dry-brush system safely removes dust, debris and other contaminants.

Maintain original sound and video quality

- Safe dry brush cleaning system

Easy to use

- Voice instructions in 14 languages

PHILIPS

Specifications

Storage Media

- Supported formats: DVD-ROM, DVD/R, DVD/RW

Accessories

- User Manual: 3 languages

Inner Carton

- Gross weight: .48 kg
- Inner carton (L x W x H): 20 x 7 x 14.7 cm
- Nett weight: .12 kg
- Tare weight: .36 kg

Outer Carton

- Gross weight: 10.48 kg
- Outer carton (L x W x H): 42.9 x 35.1 x 36.1 cm
- Nett weight: 1.44 kg
- Tare weight: 9.04 kg

Packaging dimensions

- Packaging dimensions (W x H x D):
14 x 18.5 x 1.3 cm
- Gross weight: .12 kg
- Nett weight: .02 kg
- Tare weight: .1 kg

Highlights

Dry brush system

The dry brush cleaning system safely removes dust, debris and other contaminants from the CD/DVD players laser lens, leaving it clean and performing optimally.

Voice instructions

The voice instructions on this easy to use CD lens cleaner guide you through the cleaning process in one of the 14 languages provided.



Issue date 2014-02-06

Version: 1.1.5

12 NC: 8670 000 36943
EAN: 87 12581 39469 1

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com