

Addendum





* TAB5105 and TAB5305

Equalizer (EQ) setting:

Press **EQ** on the remote control to select EQ mode.

Music/Movie/News/Stadium

LED blinks for 3 seconds to show the current EQ mode:

Item	Indicator color	EQ mode
	White	Music
	Green	Movie
	Red	News
	Cyan	Stadium