

Register your product and get support at

www.philips.com/welcome

XL300



XL305



Quick start guide

PHILIPS


1 Connect



Multi-handset version
only.


2 Get started

Configure your phone



- 1 When using your phone for the first time, you see a welcome message (country dependent).
- 2 Set the country and language if prompted.
- 3 Set the date and time.
 - If the time is in 12-hour format, press ▲ **MENU** / ▼ to select **[AM]** or **[PM]** (country dependent).

Charge your phone



Charge 8 hours



> 70%



40% - 10%



70% - 40%



< 10%

Flashing: low battery

Scrolling: charging in progress

3

Enjoy



Call

- To make a call, press /OK or  and dial the phone number.
- To answer a call, press /OK or  when the phone rings.
- To end a call, press .

Adjust the earpiece volume

Press **+** or **-** on the left side of the handset to increase/decrease the volume.

Set the direct keys

- 1 Enter the number, then press and hold **M1**, **M2** or **M3**.
- 2 Follow on-screen instructions.
- 3 To make a quick call from the record pre-saved in the direct key, press /OK or , then press **M1**, **M2** or **M3**.


Add a contact in the phonebook








- 1 Press /MENU or .
- 2 Select **[PHONEBOOK]** > **[ADD NEW]**.
- 3 Follow on-screen instructions.

Telephone answering machine

4 (XL305 only)

Listen to recorded messages



- ① To turn the answering machine on or off in standby mode, press .
- ② To delete the current message, press .
- ③ To adjust the volume, press  / .
- ④ To play the next message, press .
- ⑤ To play the previous message/replay the current message, press .
- ⑥ To start/stop listening, press .

Record an announcement

- 1 Press /MENU or .
- 2 Select [ANSW MACHINE] > [ANNOUNCEMENT].
- 3 Follow on-screen instructions.

Note

- For more information, see the Telephone answering machine section in the user manual.

i



Refer to the user manual that came with your new phone or download the latest version from www.philips.com/support.

When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC.

2013 © WOOX Innovations Limited. All rights reserved.

Philips and the Philips' Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used by WOOX Innovations Limited under license from Koninklijke Philips N.V.

CE 0168



QSG_XL300-305
05 90_EN_V2.0
WK13403

