Philips
Sandwich maker

900 W

HD2417

Have it your way, exactly your way

Set the timer for delicious sandwiches

Have your sandwiches just the way you want them. Place any sandwich you like between the large plates and select your preferred timing. The non-stick, removable, dishwasher safe plates make cleaning easier than ever before.

Delicious sandwiches
- Fits all kinds of sandwiches thanks to the large plates
- Quick and delicious results thanks to the 900 Watts of power

Exactly the way you like
- Digital timer with audible ready-signal
- Power-on and ready-to-use lights

In the easiest way
- Easy cleaning thanks to removable, dishwasher-safe plates
- Vertical, compact storage
- Finger print proof metal housing

PHILIPS
sense and simplicity

Sandwich maker
900 W

HD2417/90

Highlights

Large plates

Fits all kinds of sandwiches thanks to the large plates.

Digital timer

Digital timer with audible ready-signal.

Power-on and "ready" lights



Power-on and ready-to-use lights.

Removable, dishwasher-safe plates

Easy cleaning thanks to removable, dishwasher-safe plates.

Vertical, compact storage

Vertical, compact storage.

Finger print proof metal housing

Finger-print proof metal housing.

Specifications

General specifications

- Non-stick coated plates
- Cool touch handle
- Cord storage
- Anti-slip feet

Technical specifications

- Cord length: 0.9 m

Design specifications

- Colour(s): Black/metal/red
- Materials: Phenolic housing, metal insert on top

Issue date 2010-12-17

Version: 1.0.1

12 NC: 0000 000 00000

© 2010 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com