






AJ5000



EN User manual

**PHILIPS**

**EN**

## 1 Important

### Safety

- Read these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the clock radio.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this clock radio during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the clock radio has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the clock radio, the clock radio has been exposed to rain or moisture, does not operate normally, or has been dropped.
- This clock radio shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the clock radio (e.g. liquid filled objects, lighted candles).

- Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

## 2 Your clock radio

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at [www.philips.com/welcome](http://www.philips.com/welcome).

### Introduction

- With this unit, you can:
- listen to FM radio;
  - know the time;
  - wake up by buzzer alarm, radio, or melody; and
  - enjoy mood light.

### What's in the box (B)

Check and identify the contents of your package:

### Overview of the main unit (A)

- HR/TUNING +/-**
  - Adjust hour.
  - Tune to radio stations.
- AL1/AL2**
  - Turn on/off alarm.
  - View alarm settings.
- PROG/SCAN**
  - Scan/store radio stations.

- COLOR**
  - Select mood light color.
- SNOOZE/BRIGHTNESS**
  - Snooze alarm.
  - Adjust display brightness.
- RADIO**
  - Turn on/off radio.
  - Turn off the ringing alarm.
- SLEEP**
  - Set sleep timer.
- MIN/PRESET +/-**
  - Adjust minute.
  - Select a preset radio station.
- \* \* \***
  - Turn on/off mood light.
  - Adjust brightness level of mood light.
- CLOCK/SET AL1/SET AL2/SET TIME**
  - Set time/alarm.
  - View time.
- 12/24H-DST**
  - Select 12/24 hour format.
  - Select daylight saving time (DST) option.
- TIME ZONE**
  - Select time zone.
- WAKE TO LIGHT**
  - ON/OFF: activate/deactivate mood light when alarm sounds.
- AL1/RADIO BUZZ #1**
  - Select alarm source for Alarm 1.
- AL2/RADIO BUZZ #2**

- Select alarm source for Alarm 2.
- 16 Power cord & Antenna**
- 17 Battery tray**
- 18 VOL**
  - Adjust volume.

## 3 Get started

Always follow the instructions in this chapter in sequence.

### Install battery (C)

#### Warning

- Risk of explosion! Keep batteries away from heat, sunshine or fire. Never discard batteries in fire.
- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- The battery contains chemical substances, so it should be disposed of properly.
- Keep children away from the battery.

#### Note

- You can only use AC power as power supply. The lithium CR2032 battery is only for back-up purpose.
- When power is disconnected, the display backlight is off.

When is displayed, replace the battery as indicated.

### Connect power (F)

#### Caution

- Risk of product damage! Ensure that the power voltage corresponds to the voltage printed on the back or underside of the clock radio.
- Risk of electric shock! When you unplug the AC adapter, always pull the plug from the socket. Never pull the cord.

### Plug and set

The clock radio has "plug and set" feature. When power is connected, the clock is set automatically.

### Select time zone

Check if the time of the clock radio is consistent with the local time. If not, adjust the time zone settings, according to your location.

- In standby mode, press **TIME ZONE**.
  - ↳ The current time zone number blinks on the display panel.
- Press **TIME ZONE** repeatedly to select time zone. For Australia:

Australian Western Standard Time (AWST)	+8
Australian Central Standard Time (ACST)	+9.5
Australian Eastern Standard Time (AEST)	+10 (default)
New Zealand Standard Time (NZST)	+12

For United Kingdom and Ireland:

Western European Time (WET) +0 (default)

### Set clock (D)

In standby mode, you can set clock manually.

### Select DST (daylight saving time) mode

For countries with daylight saving time (DST), the clock radio offers you DST option to adjust summer time. In standby mode, press and hold **12/24H-DST** for two seconds. ↳ The clock advances by one hour.

#### Tip

- To exit DST mode, repeat the above operation.
- To select 12/24 hour format, press **12/24H-DST** repeatedly.

## 4 Listen to FM radio

### Tune to FM radio stations (E)

#### Note

- Position the antenna as far as possible from TV, VCR, or other radiation source.
- For optimal reception, fully extend and adjust the position of the antenna.



