

www.philips.com/support

BM7



User manual

PHILIPS

Contents

1	Important	2
	Safety	2

2	Your multiroom speaker	3
	Introduction	3
	What's in the box	3
	Overview of the main unit	4

3	Prepare	6
	Connect power and turn on	6

4	Play	7
	Play in single mode	7
	Play in group mode	9
	Control play	11

5	Other features	12
	Update firmware	12
	Reset group status	12

6	Product information	13
	Specifications	13

7	Troubleshooting	14
----------	------------------------	-----------

8	Understand meanings of LED status	15
----------	--	-----------

9	Notice	17
	Written offer	17

1 Important

Safety

- Make sure that there is enough free space around the product for ventilation.
- Only use attachments or accessories specified by the manufacturer.
- Use only power supplies listed in the user manual.
- The product shall not be exposed to dripping or splashing.
- Do not place any sources of danger on the product (e.g. liquid filled objects, lighted candles).
- Where the plug the Direct Plug-in Adapter or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.



Warning

- Never remove the casing of this unit.
- Never lubricate any part of this unit.
- Place this unit on a flat, hard and stable surface.
- Never place this unit on other electrical equipment.
- Only use this unit indoors. Keep this unit away from water; moisture and liquid-filled objects.
- Keep this unit away from direct sunlight, naked flames or heat.



This is CLASS II apparatus with double insulation, and no protective earth provided.

2 Your multiroom speaker

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Introduction

With the Philips izzylink speaker, you can:



- listen to music from your Bluetooth-enabled devices;
- listen to music everywhere in your home through a group of izzylink-compatible multiroom speakers (not supplied);
- listen to music from an external audio device through a 3,5mm audio cable.

What's in the box

Check and identify the contents of your package:

- 1 × izzylink multiroom speaker
- 1 × power adapter
- Printed materials

Overview of the main unit



- ① **Power**
 - Turn the speaker on or off.
- ② **SOURCE**
 - Switch to the Bluetooth or AUDIO IN source.
 - In Bluetooth mode, press and hold for three seconds to disconnect the current Bluetooth connection.
 - In Bluetooth mode, press and hold for ten seconds to clear the pairing information.
- ③ **▶||**
 - Start, pause, or resume play.
- ④ **GROUP button/indicator**
 - Press and hold to group with another izzylink-compatible multiroom speaker.
 - Press to exit or return to a group.
 - Flashes green during grouping.
 - Turns solid green after successful grouping.
 - Flashes green when the speaker acts as a slave and is disconnected from its master.
- ⑤ **Volume knob**
 - Turn clockwise/anticlockwise to increase/decrease volume.
 - Press to mute/unmute the speaker.
- ⑥ **Volume indicator**
 - Lights up after power-on.
 - Dims in standby mode.
 - Flashes when the speaker is muted.
 - Turns green when the speaker acts as a slave in a group of speakers.
- ⑦ **AUDIO IN indicator**
 - Lights up white when the selected source is AUDIO IN.
 - Turns off in power-off/standby mode or when the speaker acts as a slave in a group of speakers.
- ⑧ **Bluetooth indicator**
 - Flashes blue in pairing mode.
 - Turns solid blue after successful connection with a Bluetooth-enabled device.
 - Turns off in power-off/standby mode or when the speaker acts as a slave in a group of speakers.
- ⑨ **Signal strength indicator**
 - Indicates the signal strength of group connection.
- ⑩ **AUDIO IN socket**
 - Audio input socket (3,5mm) for an external audio device.

- ⑪ **DC IN socket**
 - Power socket.
- ⑫ **SOFTWARE UPGRADE**
 - USB socket for speaker software upgrade only.
- ⑬ **GROUP RESET**
 - Press with a sharp object to restore factory defaults.

3 Prepare

Always follow the instructions in this chapter in sequence.

If you contact Philips, you will be asked for the model and serial number of this apparatus. The model number and serial number are on the bottom of the apparatus. Write the numbers here:


Model No. _____

Serial No. _____

Connect power and turn on

Caution

- Risk of product damage! Make sure that the power supply voltage corresponds to the voltage printed on the bottom of the speaker.
- Risk of electric shock! When you unplug the AC power adapter, always pull the plug from the socket. Never pull the cord.
- Before you connect the AC power adapter, make sure that you have completed all the other connections.



- Connect the power adapter to
 - the **DC IN** socket on the back of the speaker.
 - the wall power socket.

↳ The volume indicator lights up.

↳ The signal strength indicators flash for several seconds until the speaker boots up.

- ↳ For first-time use or in single mode, the **B** indicator starts flashing and the speaker enters pairing mode.
- ↳ When the speaker acts as the master in group mode, the **B** indicator starts flashing until the speaker finds the last paired Bluetooth-enabled device.
- ↳ When the speaker acts as a slave in group mode, the **GROUP** indicator starts flashing until the speaker finds its master in the group.

Tip

- Single mode indicates to use a speaker as a single Bluetooth speaker that does not act as a master or slave in a group of speakers.
- Group mode indicates that several izzylink-compatible multiroom speakers form a group, with one speaker acting as the master and the others as slaves.

Switch to standby mode

- In single mode, press **⏻**.
 - ↳ The volume indicator dims.
 - ↳ All the other indicators turn off.
- In group mode, press **⏻** on any speaker in the group.
 - ↳ The volume indicator on each speaker in the group dims.
 - ↳ All the other indicators turn off.
- In single mode, to switch on from standby mode, press **⏻** again.
- In group mode, press **⏻** on any speaker in the group to switch all the speakers on from standby mode.

Note

- You can hold **⏻** to turn off the volume indicator completely.
- In single mode, if the Bluetooth connection is invalid or music playback is stopped for 15 minutes, the speaker switches to standby mode automatically.
- In group mode, if the Bluetooth connection with the master speaker is invalid or music playback is stopped for 15 minutes, all the speakers in the group switch to standby mode automatically.

4 Play

Play in single mode

Single mode: Single mode means that the speaker is not grouped with any other izzylink-compatible multiroom speakers. Instead, it is used as a standalone speaker.

Pair and connect

Connect a Bluetooth-enabled device

Note

- Make sure that your Bluetooth-enabled device is compatible with this speaker.
- Before pairing a device with this speaker, read its user manual for Bluetooth compatibility.
- Make sure that the Bluetooth function is enabled on your device, and your device is set as visible to all other Bluetooth devices.
- Any obstacle between this speaker and a Bluetooth device can reduce the operational range.
- Keep away from any other electronic device that may cause interference.
- The operational range between this speaker and a Bluetooth device is approximately 10 meters (30 feet).

Option 1: Pair and connect through NFC


Near Field Communication (NFC) is a technology that enables short-range wireless communication between various NFC compatible devices, such as mobile phones and IC tags.

With the NFC function, data communication can be achieved easily just by touching the relevant symbol or designated location on NFC compatible devices.

Note


- Compatibility with all NFC devices is not guaranteed.

NFC



- 1 Enable the NFC feature on your Bluetooth enabled device (see the user manual of the device for details).
- 2 Press SOURCE repeatedly to switch to Bluetooth source and enter pairing mode.
↳ The **B** indicator flashes blue.
- 3 Touch the NFC area of the external device with the NFC area on the top of the unit until you hear a beep.
↳ After successful pairing and connection, the speaker beeps twice, and the **B** indicator turns solid blue.

Option 2: Pair and connect manually



- 1 Press **SOURCE** repeatedly to switch to Bluetooth source and enter pairing mode.
 - ↳ The  indicator flashes blue.
- 2 On your Bluetooth device, enable Bluetooth and search for Bluetooth devices (refer to the user manual of the device).
- 3 When [**Philips BM7 XXXX**] is displayed on your device, select it to start pairing and connection. If necessary, enter the default password "0000".
 - ↳ After successful pairing and connection, the speaker beeps twice, and the  indicator turns solid blue.

Play from the connected Bluetooth-enabled device

Note

- Music play pauses when there is an incoming call or video recording is in progress on the connected mobile phone.
- After successful Bluetooth connection, play music on the Bluetooth device.
 - ↳ Music streams from your Bluetooth device to the speaker.

To disconnect the Bluetooth-enabled device:

- Disable Bluetooth on your device;
- In Bluetooth mode, press and hold **SOURCE** on the speaker for more than three seconds; or
- Move the device beyond the communication range.

To clear the pairing information:

- In Bluetooth mode, press and hold **SOURCE** on the speaker for more than ten seconds.

To reconnect the Bluetooth-enabled device:

- For a paired Bluetooth device on which automatic reconnection is enabled, this speaker reconnects with it once it is detected.
- For a paired Bluetooth device that does not support automatic reconnection, reconnect it with this speaker manually.

To connect another Bluetooth-enabled device:

- Disable Bluetooth on the current device, and connect another device when the indicator flashes blue.


Tip

- Before you reconnect a Bluetooth-enabled device (especially an iOS device) to the speaker, you may need to clear the previous pairing information on your device.

 indicator	Description
Flashing blue	Connecting or waiting for connection
Solid blue	Connected

Listen to an external device

You can listen to an external audio device such as an MP3 player through the **AUDIO IN** socket on the speaker.




- 1 Connect an audio cable with a 3.5 mm connector on both ends to
 - the **AUDIO IN** socket on the speaker, and
 - the headphone socket on the external device.
- 2 Press **SOURCE** repeatedly to switch to the AUDIO IN source.
 - ↳ The **AUDIO IN** indicator lights up white.
- 3 Play music on the external device (refer to its user manual).

Play in group mode


Group mode: If you have more than one izzylink-compatible multiroom speakers, you can create a group and stream music to the group of speakers at the same time. To use this feature, you need to purchase more than one izzylink-compatible multiroom speakers.

Note

- You can create a group of up to five speakers, with one as the master and four as slaves.



Create a group



Note

- Whenever you create a group, the first speaker that you enable the group function will act as the master.

- 1 Hold **GROUP** on the first speaker for 3 seconds (The master).
- 2 Hold **GROUP** on a second speaker for 3 seconds (The slave).
- 3 Wait for 15 to 30 seconds for connection setup.
- 4 Repeat steps 1 to 3 to add more slave speakers one by one.

Note

- You can only add slave speakers one by one. Each time when you add a slave speaker; first press and hold **GROUP** on the master speaker until the indicator on the button flashes and the speaker beeps.
- If the signal strength indicator on a slave speaker shows that the signal is poor; move it closer to the master speaker.

You can add any of the following speakers into the existing group or create a new group with them:

- A speaker with factory default settings
- A master speaker that has no slave connected to it
- A slave speaker that is disconnected from its master (with the **GROUP** indicator flashing)

Play from the master to the whole group

Note

- In Bluetooth mode, music play pauses when there is an incoming call or video recording is in progress on the connected mobile phone.
- If this speaker (BM7) acts as the master, select a source and play to the whole group of speakers.


Change master

You can change the current master in a group easily. For example, when the Bluetooth connection with the current master speaker is lost, you can set the closest slave speaker as the master.



- Press any source key on a slave speaker to change it to be the master of the group.
 - ↳ Pair your mobile device with the new master if you have not paired with it before.

Switch to single mode



- Press **GROUP** on the master to enter single mode.
 - ↳ The slaves keep looking for the master until timeout in 15 minutes.
 - ↳ You can create a new group with the slaves or press **GROUP** on a slave to enter single mode.
 - Press **GROUP** on the master again to resume group mode.
- Press **GROUP** on a slave to switch to single mode. Press **GROUP** again to rejoin.

Control play



Note

- Due to data buffering, you may experience some delay when you play/pause or adjust volume from the Bluetooth device.

Control from the speaker

-  • In single mode, turn the speaker on/off.
- In group mode, turn the whole group of speakers on/off.

-  (unavailable in AUDIO IN mode)
- In single mode, pause/resume play of the current speaker.
 - In group mode, pause/resume play of the whole group.

- Volume knob**
- Press to mute/unmute the current speaker:
 - ↳ The volume indicator flashes when the speaker is muted.
 - Turn clockwise/anticlockwise to increase/decrease volume of the current speaker.

Control from the connected Bluetooth device

You can use controls on your Bluetooth device directly.

5 Other features

Update firmware


Warning

- Always connect the speaker to AC power for firmware upgrade.
- Never power off the speaker or unplug the USB mass storage device before completion of the firmware upgrade.


Note

- Make sure that the USB stick is FAT16/32 formatted.

- 1 On your PC/Mac, go to www.philips.com/support.
- 2 Enter the model number to find the latest firmware upgrade file available.




- 3 Unzip and save the upgrade file (BM7.bin) to the root directory of a USB stick.
- 4 Disconnect the AC power of the speaker.
- 5 Plug the USB stick into the USB socket on the back of the speaker.



- 6 Connect AC power again and turn on the speaker.
- 7 Do not remove the USB stick, and wait for around 3 to 4 minutes for completion of the firmware upgrade.
 - ↳ At completion of firmware upgrade, all indicators on the speaker flash at the same time.

Reset group status



- In case of any grouping issues, you can reset the speaker with a sharp object such as a needle.
 - ↳ The speaker reboots automatically.

6 Product information

Note

- Product information is subject to change without prior notice.

Specifications

Amplifier

Rated Output Power	2 X15W RMS at 1% THD
Frequency Response	40 -20000 Hz
Signal to Noise Ratio	72dBA
Audio-in Input	950mV RMS 20kohm

Bluetooth

Bluetooth version	V2.1 + EDR
Bluetooth Profile	A2DP AVRCP
Range	10 m (free space)

Speakers

Speaker Driver	3.5" Woofer x2 1" Tweeter x2
Speaker Impedance	8 ohm 8 ohm
Sensitivity	86dB/m/W 85dB/m/W

General information

AC power PHILIPS	Input: 100-240 V~ 50/60 Hz
Switching power supply model: GQ30-180165-AX	Output: DC 18V \equiv 1.65A
Operation Power Consumption	4,59 W
Eco Standby Power Consumption	< 0.5 W
Dimensions - Main Unit (W x H x D)	280 x 130 x 165 mm
Weight - Main Unit	2.33 kg

7 Troubleshooting



Warning

- Never remove the casing of this device.

To keep the warranty valid, never try to repair the system yourself.

If you encounter problems when using this device, check the following points before requesting service. If the problem remains unsolved, go to the Philips Web page (www.philips.com/support). When you contact Philips, make sure that the device is nearby and the model number and serial number are available.

No power

- Make sure that the AC power cord of the speaker is connected properly.
- Make sure that there is power at the AC outlet.
- As a power-saving feature, the speaker switches off automatically after 15 minutes of inactivity.

No sound

- Adjust volume.
- Check whether the speaker is muted.

Some buttons on the unit do not work or the unit is not working as usual.

- You may have activated demo mode by accident. In this case, unplug the power cable, press and hold ϕ and then plug in the power cable again. Continue to hold the button for 15 seconds until all indicators flash to exit demo mode. If the issue remains, repeat the operation. Then you can power on and operate the speaker as usual.

No response from the speaker

- Disconnect and reconnect the AC power plug, then turn on the speaker again.

Music playback is unavailable on this speaker even after successful Bluetooth connection.

- Check whether the current audio source of the speaker is AUDIO IN. Unplug the 3.5mm audio cable.

- The device cannot be used to play music through this speaker wirelessly.

The audio quality is poor after connection with a Bluetooth-enabled device.

- The Bluetooth reception is poor: Move the device closer to this speaker or remove any obstacle between them.

Bluetooth cannot be connected with this speaker.

- The device does not support the Bluetooth profiles required for this speaker.
- The Bluetooth function of the device is not enabled. Refer to the user manual of the device to find out how to enable the function.
- This speaker is not in pairing mode or acts as a slave in a group. In group mode, you can only set up Bluetooth connection with the master speaker.
- This speaker is already connected with another Bluetooth-enabled device. Disconnect that device and then try again.


Group connection failed

- Move slave speakers closer to the master.
- You can only add slave speakers one by one.
- You cannot group more than four speakers with the master.
- The master speaker may have switched to single mode.

Occasional stuttering or breaking of music streaming during group playback

- If you experience music stuttering or breaking of streaming, it could be that your home Wi-Fi network is busy. Even though Izzylink is independent from your home Wi-Fi network, it uses Wi-Fi signals to communicate between the speakers. Try the following : 1) Reduce traffic on your home Wi-Fi network, e.g. stop any large file downloads or other content streaming on your Wi-Fi network; 2) Reboot the Master speaker, by unplugging it from the mains and plugging it in again.

8 Understand meanings of LED status



(1) Group indicator status

Meaning
Off

The speaker is powered off.
The speaker is in single mode.

Flashing green

The speaker is grouping with its master/slave.
The speaker acts as a slave and is disconnected from its master.

Solid green

The speaker is grouped with its master/slave.
The speaker acts as the master and is disconnected from its slaves.

(2) Status of streaming quality indicators

Meaning
All three indicators lighting up

The signal strength of group connection is excellent.

Two indicators lighting up

The signal strength of group connection is good.

Only one indicator lighting up	The signal strength of group connection is poor. Move slave speakers closer to the master speaker.
--------------------------------	--

No indicator lighting up	The speaker is powered off or working in single mode, or the group connection fails.
--------------------------	--

(3) Bluetooth indicator status

Meaning
Off

The speaker is powered off.
The speaker acts as a slave in group mode.
The speaker is grouping with its master/slave.

Flashing blue

The speaker is in pairing mode.

Solid blue

The speaker is connected to a Bluetooth-enabled device.

(4) AUDIO IN indicator status

Meaning
Off

The speaker is powered off.
The speaker acts as a slave in group mode.
The speaker is grouping with its master/slave.

Solid white

In single mode or when the speaker acts as the master in a group, the current source of the speaker is AUDIO IN.

(5) Volume indicator status

Meaning
Off

The speaker is powered off.

Solid white in full brightness

The speaker is powered on in single mode.
The speaker is powered on when it acts as the master in group mode.

Solid green in full brightness	The speaker is powered on when it acts as a slave in group mode.
Solid white in half brightness	The speaker switches to standby in single mode. The speaker switches to standby when it acts as the master in group mode.
Solid green in half brightness	The speaker switches to standby when it acts as a slave in group mode.
Flashing white	The speaker is muted in single mode. The speaker is muted when it acts as the master in group mode.
Flashing green	The speaker is muted when it acts as a slave in group mode.

9 Notice

CE 1588

Hereby, Gibson Innovations declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. You can find the Declaration of Conformity on www.p4c.philips.com.

Any changes or modifications made to this device that are not expressly approved by Gibson Innovations may void the user's authority to operate the equipment.

Disposal of your old product



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



This symbol on a product means that the product is covered by European Directive 2012/19/EU. Inform yourself about the local separate collection system for electrical and electronic products. Follow local rules and never dispose of the product with normal household waste. Correct disposal of old products helps prevent negative consequences for the environment and human health.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.)

Your system consists of materials which can be recycled and reused if disassembled by

a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Gibson Innovations Limited is under license. Other trademarks and trade names are those of their respective owners.



The N Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.



Note

- The type plate is located on the bottom of the product.

Written offer

Gibson Innovations Limited hereby offers to deliver, upon request, a copy of the corresponding source code for the open source software packages used in this product for which such offer is requested by the respective licenses. This offer is valid up to three years after product purchase. To obtain source code, please contact open.source-gi@gibson.com. If you prefer not to use email or if you do not receive confirmation receipt within a week after mailing to this email address, please write to Open Source Team, Gibson Innovations Limited, 5/F Philips Electronics Building, 5 Science Park East Avenue, Hong Kong Science Park, Shatin, N.T. Hong Kong.



2016 © Gibson Innovations Limited. All rights reserved.

This product has been manufactured by, and is sold under the responsibility of Gibson Innovations Ltd., and © 2016 Gibson Innovations Limited. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Gibson Innovations Ltd., registered in the Netherlands. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license from Koninklijke Philips N.V.

BM7_10_UM_V2.0

