



PHILIPS
AVENT



www.philips.com/avent

Philips Consumer Lifestyle BV

Tussendiepen 4, 9206 AD Drachten, Netherlands

Trademarks owned by the Philips Group.

©2015 Koninklijke Philips N.V. All rights reserved







www.philips.com



>75% recycled paper

4213.354.3760.2 (11/15)



EN For your child's safety and health WARNING!

- Always use this product with adult supervision.
- Never use feeding teats as a soother.
- Continuous and prolonged sipping of fluids will cause tooth decay.
- Always check food temperature before feeding.
- Keep all components not in use out of the reach of children.
- Do not allow children to play with small parts or walk/run while using bottles or cups.
- Do not place in a heated oven.
- Heating in a microwave oven may produce localised high temperatures. Take extra care when you heat up drinks in a microwave.
- To avoid scalding, allow hot liquids to cool before preparing the feeds.
- Drinks other than milk and water, such as fruit juices and flavoured sugary drinks are not recommended. If they are used, they should be well diluted and only used for limited periods, not constantly sipped.
- To ensure the bottle functions correctly and to prevent leakage, always make sure you remove any debris or residue that may collect around the rim of the bottle before assembly, and avoid over-tightening the bottle screw ring when assembling it onto the bottle.
- Expressed breast milk can be stored in sterilised Philips Avent polypropylene bottles/containers in the refrigerator for up to 48 hours (not in the door) or the freezer for up to 3 months. Never refreeze breast milk or add fresh breast milk to already frozen milk.

Before first use

- Clean and sterilise the product.
- Place in boiling water for 5 minutes. This is to ensure hygiene.

Clean before each use

- Wash and rinse all parts thoroughly in warm water and some washing-up liquid, then sterilise using a Philips Avent steriliser or boil for 5 minutes.
- Wash your hands thoroughly and ensure surfaces are clean before contact with sterilised components. Do not place components directly on surfaces that have been cleaned with antibacterial cleaning agents. Excessive concentration of cleaning agents may eventually cause plastic components to crack. Should this occur, replace immediately.
- Plastic material properties may be affected by sterilising and high temperatures. This can affect the fit of the cap.
- Dishwasher safe – food colourings may discolour components.

Assembling the bottle

- The teat is easier to assemble if you wriggle it upwards instead of pulling it up in a straight line.
- Make sure you pull the teat through until its lower part is aligned with the screw ring.
- When you assemble the bottle, make sure you place the cap horizontally onto the bottle so that the teat sits upright.
- To remove the cap, place your hand over the cap and your thumb in the dimple of the cap.

Teats

- Inspect before each use and pull the feeding teat in all directions. Throw away at the first signs of damage or weakness.
- For hygiene reasons, we recommend replacing teats after 3 months.
- Keep teats in a dry and covered container.
- Do not store a feeding teat in direct sunlight or heat, or leave in disinfectant (sterilising solution) for longer than recommended, as this may weaken the teat.
- Make sure you use a teat with the correct flow rate when you feed your baby.
- Teats are available in newborn, slow, medium, fast and variable flow rates. Only use Philips Avent Natural teats with Philips Avent Natural bottles.
- To buy accessories or spare parts, visit www.shop.philips.com or service or go to your Philips dealer. You can also contact the Philips Consumer Care Centre in your country.
- Compatibility
- This bottle is not compatible with Philips Avent bottle warmers.

BG За безопасността и здравето на вашето дете ПРЕДУПРЕЖДЕНИЕ!

- Този продукт трябва да се използва винаги под родителски надзор.
- Не използвайте бибероните за хранене като залягалки.
- Непрекъснатото и продължително изсмукване на течности води до увреждане на зъбите.
- Винаги проверявайте температурата на храната преди хранене.
- Пазете всички компоненти, които не се използват, извън достъпа на деца.
- Не позволявайте на децата да си играят с малки части, нито да вървят/тичат, докато използват бутилки или чаши.
- Не поставяйте в загрята фурна.
- Затоплянето в микровълнова печка може да доведе до локализиран високи температури. Бъдете много внимателни при загряване на напитки в микровълнова печка.
- За да не се опарите, оставете горещите течности да изстинат, преди да пригответе хранителната доза.
- Не се препоръчват други напитки, освен мляко и вода, например плодови сокове и подсладени сиропи. Ако се използват такива, трябва да са надлежно разреждени и да се използват само за ограничен период от време, а не да се пият постоянно.
- За да се гарантира правилното функциониране на бутилката и за да се предотврати изтичане, винаги проверявайте дали сте отстранили замърсяванията или остатъците, които може да се съберат около гърлото на бутилката преди сглобяването, и внимавайте да не затегнете прекомерно винтовия пръстен, когато го поставяте на бутилката.
- Изцедената кърма може да се съхранява в стерилизирани полипропиленови бутилки/контейнери Philips Avent в хладилник до 48 часа (не на вратата на хладилника) или във фризер до 3 месеца. Никога не замразявайте кърма повторно и не добавяйте нова кърма към вече замразената.