



size:H85 x W60mm



# LED Adapter

EN Installation guide

中文 安装指导




Lumileds is the warrantor of this product.  
The Philips trademarks are used under license  
from Koninklijke Philips N.V. (2017).  
© Lumileds Holding B.V. 2017. All rights reserved


3211 008 22781

## Installation guide

- Plug LED adapter into car lamp socket and LED lamp header.
- Fix LED adapter body to the metal frame of engine room with belt.
- Please make sure to keep the seal after installation.




2



HB3/4 & HIR2, H11 & Fog and H7 installation same as H4

## Caution


- The LED Adapter gets hot on the working condition, please do not touch until it fully cool down.
- The LED Adapter must be fixed onto the metal frame of engine room, please do not fix it onto the cables, pipes, plastic or hot materials.




3

## 安装指导

- 将LED解码器分别与汽车车灯接口和LED灯接口连接；
- 将LED解码器本体固定在引擎仓的内部金属框架上；
- 安装后，请保持原来的密封环境。




4



HB3/4 & HIR2, H11 & Fog 和 H7 安装方式与 H4相同

## 注意

- LED解码器在工作中会发热，在冷却前请勿触摸；
- LED解码器必须固定在引擎仓金属框架上，严禁固定于线束，管道，塑料或发热物体表面。



5