

ENGLISH

POWER SUPPLY

Battery (not included)

- Open battery door and insert two alkaline batteries, type **R03,UM4** or **AAA** as indicated.
- Remove the batteries from the set if they are exhausted or not to be used for a long time.
- When the batteries are running low, 🔋 flashes in the display. If the radio is on, it will automatically switch off.
- It may be necessary to reprogramme your preset stations.

SETTING THE CLOCK

When the radio is off, the time is displayed using the 24-hour clock or the 12 clock system with **AM** and **PM** indication.

- Check the radio is switched off.
- Press **TIMESET** on the back panel.
- To set the hours/minutes, press **TUNING ▲** or **▼** (**HR** or **MIN**) *while the display is still flashing*.
 - With your finger held down on **▲/▼**, the hour/minute increases continuously. Release **▲/▼** when you reach the correct hour/minute setting.
 - Press **▲/▼** briefly and repeatedly if you need to adjust the hours/ minutes slowly.

To adjust the 9/10 kHz AM tuning step and clock display

In North and South America the frequency step between adjacent AM band channels is 10kHz. In the rest of the world e.g. Europe, this step is 9 kHz. Usually the frequency step has been preset in the factory for your area.

- Open the battery door. With a ballpoint pen tip adjust the **9K/10K** tuning step switch to select your tuning step.
- With a ballpoint pen tip press the **RESET** hole.
 - The display will either show:

- 0:00 for **9kHz** and a 24-hour clock display.
 - 12:00 for **10kHz** and a 12-hour clock display.
- All previous preset stations and the time will need to be re-entered.

RADIO RECEPTION

- Connect headphones to the 👂 socket.
- Press Ⓚ **POWER/ BAND** to switch on the radio.
- Press Ⓚ **POWER/ BAND** once or more to select **AM** or **FM** waveband.
 - The display shows the radio station details throughout the radio mode.
 - STEREO** appears when you are receiving a FM stereo transmission.
- Select your station by using a preset number (1-5), or **TUNING ▲** or **▼** (+ or −).

To improve reception:

FM: The headphone cord functions as the FM-aerial. Extend it fully to the yellow mark and position the cord.

AM: Uses a built-in aerial. Turn the set to find the best position.

- Adjust the sound with **VOLUME** and **DBB ON+OFF**.
- To switch off the radio, press Ⓚ **POWER/ BAND**, once or more until **OFF** appears briefly.

TUNING

Manual tuning

- Press **TUNING ▲** or **▼** (+ or −) briefly, once or more until the right frequency is found.

Automatic tuning

- Press and hold down **TUNING ▲** or **▼** (+ or −) until the display frequency starts to run.
- When a station of sufficient strength has been found tuning stops, or you can stop automatic tuning by pressing **TUNING ▲** or **▼** again.

Meet **PHILIPS** at the internet <http://www.philips.com>

inted in Hong Kong TC text/RB/9852

FRAŅAIS

ALIMENTATION

Piles (non comprises à la livraison)

- Ouvrez le compartiment des piles pour y introduire deux piles alcalines de type **R03, UM4** ou **AAA** de la manière indiquée.
- Enlevez les piles dès qu'elles sont usagées ou qu'elles n'ont pas été utilisées pendant une période prolongée.
- Si les piles ont une faible capacité, 🔋 clignote sur l'écran. Si la radio est en service, la mise hors service se fera automatiquement.
- Il sera parfois nécessaire de reprogrammer les stations mémorisées.

REGLAGE DE L'HORLOGE

Lorsque la radio est mise hors service, l'heure est affichée sur 24 heures ou sur 12 heures avec indication **AM** (matin) et **PM** (après-midi).

- Contrôlez si la radio est hors service.
- Appuyez sur **TIMESET** sur le panneau arrière.
- Pour régler les heures et les minutes, appuyez sur **TUNING ▲** ou **▼** (**HR** ou **MIN**) *lorsque l'affichage clignote*.
 - L'écran affiche les heures et le doigt sur **▲** ou **▼**, pour faire défiler les heures/minutes. Relâchez la touche **▲/▼** lorsque le réglage des heures ou des minutes est correct.
 - Appuyez brièvement et de manière répétée sur **▲** ou **▼** pour régler lentement les heures et les minutes.

Pour régler l'intervalle de fréquence AM 9/10 kHz /l'affichage de l'heure

En Amérique du nord et du sud, l'intervalle de fréquence entre les canaux adjacents en bande AM est de 10 kHz. Dans le reste du monde, dont l'Europe, cet intervalle est de 9 kHz. En règle générale, l'intervalle de fréquence a été réglée en usine pour votre région.

- Ouvrez le compartiment des piles. Avec l'aide d'une pointe de stylo, réglez le sélecteur d'intervalle d'accord **9K/10K** sur la valeur voulue.
- Enfoncez une pointe de stylo à bille dans le trou **RESET**.
- L'écran indiquer alors:

Soit 0:00 pour **9kHz** et l'affichage de l'heure sur 24 heures.

Soit 12:00 pour **10kHz** et l'affichage de l'heure sur 12 heures.

- Toutes les stations pré-réglées au préalable et l'heure devront être reprogrammées.

RECEPTION RADIO

- Branchez les écouteurs dans la prise 👂.
 - Appuyez sur Ⓚ **POWER/ BAND** pour mettre la radio en marche.
 - Appuyez une seule ou plusieurs fois sur Ⓚ **POWER/ BAND** pour sélectionner la bande **AM** ou **FM**.
 - L'écran affiche les données de la station radio tant que l'appareil est en mode radio.
 - STEREO** s'affiche lorsque vous recevez une émission FM stéréo.
 - Sélectionnez la station voulue à l'aide de l'un des numéros de présélection (1 à 5), ou en appuyant sur **TUNING ▲** ou **▼** (+ ou −).
- Pour améliorer la réception:*
- FM:** Le cordon des écouteurs fait office d'antenne FM. Déroulez-le entièrement jusqu'au repère jaune et positionnez-le.
- AM:** Utilisez l'antenne intégrée. Orientez l'appareil pour obtenir la meilleure réception.
- Réglez le son à l'aide du bouton **VOLUME** et **DBB ON+OFF**.
 - Pour mettre la radio hors service, appuyez une seule ou plusieurs fois sur Ⓚ **POWER/ BAND**, jusqu'à ce qu'OFF apparaisse un bref instant.

RECHERCHE DES FREQUENCES

Recherche manuelle

- Appuyez une seule ou plusieurs fois brièvement sur **TUNING ▲** ou **▼** (+ ou −) pour rechercher la fréquence voulue.

Recherche automatique

- Appuyez sans relâcher le doigt sur **TUNING ▲** ou **▼** (+ ou −) jusqu'à ce que l'affichage de la fréquence commence à défiler.
- Lorsqu'une station de puissance suffisante a été détectée, la recherche s'arrête. Vous pouvez aussi arrêter la recherche automatique en appuyant de nouveau sur **TUNING ▲** ou **▼**.

ESPAÑOL

FUENTE DE ALIMENTACIÓN

Pilas (no incluidas)

- Abra el compartimento de las pilas e introduzca 2 pilas alcalinas, tipo **R03, UM4** o **AAA** como se indica.
- Si las pilas están desgastadas o no va a utilizar el aparato durante un largo período, extráigalas del aparato.
- Si las pilas están desgastadas, 🔋 parpadea en el visor. Si la radio está encendida, se apagará automáticamente.
- Probablemente necesitará volver a programar las emisoras presintonizadas.

AJUSTE DEL RELOJ

Con la radio apagada, el visor muestra el sistema de horario del reloj de 24 horas o del de 12 horas: indicaciones **AM** (mañana) y **PM** (tarde).

- Asegúrese de que la radio está apagada.
- Pulse **TIMESET** en la parte posterior del panel.
- Para ajustar las horas/minutos, pulse **TUNING ▲** o **▼** (**HR** o **MIN**) *mientras la pantalla parpadea*.
 - Mantenga presionado **▲/▼** con el dedo para que la hora/minutos aumenten continuamente. Suelte **▲/▼** cuando haya llegado al ajuste correcto.
 - Pulse **▲/▼** breve y repetidamente si necesita ajustar despacio la hora/minutos.

TROUBLESHOOTING

If a fault occurs, first check the points listed below before taking the set for repair. If you are unable to remedy a problem by following these hints, consult your dealer or service centre.

***WARNING:** Under no circumstances should you try to repair the set yourself, as this will invalidate your guarantee.*

Poor sound/ no sound:




- Headphone plug not fully inserted
- Insert plug fully for personal listening
- Wrong battery polarity
- Insert batteries correctly

Severe radio hum/distortion:

- FM aerial (headphone cord) not fully extended
- Extend FM aerial fully
- Set too close to TV, computer, etc.
- Move set away from other electrical equipment

Digital controls/ display does not function properly

- Electrostatic discharge
- Use the tip of a ball-point pen to press the RESET hole and then reprogramme settings



CINESE

POWER SUPPLY

Battery (not included)

- Open battery door and insert two alkaline batteries, type **R03,UM4** or **AAA** as indicated.
- Remove the batteries from the set if they are exhausted or not to be used for a long time.
- When the batteries are running low, ⏏ flashes in the display. If the radio is on, it will automatically switch off.
- It may be necessary to reprogramme your preset stations.

SETTING THE CLOCK

When the radio is off, the time is displayed using the 24-hour clock or the 12 clock system with ***AM*** and ***PM*** indication.

- Check the radio is switched off.
- Press **TIMESET** on the back panel.
- To set the hours/minutes, press **TUNING ▲** or **▼ (HR or MIN)** while the display is still flashing.
 - With your finger held down on **▲/▼**, the hour/minute increases continuously. Release **▲/▼** when you reach the correct hour/minute setting.
 - Press **▲/▼** briefly and repeatedly if you need to adjust the hours/ minutes slowly.

To adjust the 9/10 kHz AM tuning step and clock display

In North and South America the frequency step between adjacent AM band channels is 10kHz. In the rest of the world e.g. Europe, this step is 9 kHz. Usually the frequency step has been preset in the factory for your area.

- Open the battery door. With a ballpoint pen tip adjust the **9K/10K** tuning step switch to select your tuning step.
- With a ballpoint pen tip press the **RESET** hole.
 - The display will either show:

0:00 for **9kHz** and a 24-hour clock display.

12:00 for **10kHz** and a 12-hour clock display.

- All previous preset stations and the time will need to be re-entered.

RADIO RECEPTION

- Connect headphones to the 👂 socket.
- Press Ⓚ **POWER/ BAND** to switch on the radio.
- Press Ⓚ **POWER/ BAND** once or more to select ***AM*** or ***FM*** waveband.
 - The display shows the radio station details throughout the radio mode.
 - STEREO*** appears when you are receiving a FM stereo transmission.
- Select your station by using a preset number (1-5), or **TUNING ▲** or **▼** (+ or –).

To improve reception:

FM: The headphone cord functions as the FM-aerial. Extend it fully to the yellow mark and position the cord.

AM: Uses a built-in aerial. Turn the set to find the best position.

- Adjust the sound with **VOLUME** and **DBB ON-OFF**.
- To switch off the radio, press Ⓚ **POWER/ BAND**, once or more until ***OFF*** appears briefly.

TUNING

Manual tuning

- Press **TUNING ▲** or **▼** (+ or –) briefly, once or more until the right frequency is found.

Automatic tuning

- Press and hold down **TUNING ▲** or **▼** (+ or –) until the display frequency starts to run.
- When a station of sufficient strength has been found tuning stops, or you can stop automatic tuning by pressing **TUNING ▲** or **▼** again.

TROUBLESHOOTING

If a fault occurs, first check the points listed below before taking the set for repair. If you are unable to remedy a problem by following these hints, consult your dealer or service centre.

***WARNING:** Under no circumstances should you try to repair the set yourself, as this will invalidate your guarantee.*

Poor sound/ no sound:

- Headphone plug not fully inserted*
- Insert plug fully for personal listening
- Wrong battery polarity*
- Insert batteries correctly

Severe radio hum/distortion:

- FM aerial (headphone cord) not fully extended*
- Extend FM aerial fully
- Set too close to TV, computer, etc.*
- Move set away from other electrical equipment
- Batteries weak*
- Insert fresh batteries

Digital controls/ display does not function properly

- Electrostatic discharge*
- Use the tip of a ball-point pen to press the RESET hole and then reprogramme settings

The model number is found at the back panel and the production number in the battery compartment.

AUSTRALIA

Philips product warranty for Australia

Warranty conditions valid for Colour Television, Video Cassette Recorders, Audio Systems, and Portable Audio.

The benefits given to the purchaser by this warranty are in addition to all other rights and remedies which the purchaser has in respect of the product under the Trade Practices Act or other Commonwealth or State Law. Philips Sound and Vision warrants it's products to the purchaser as follows and subject to the stated conditions.

12 months free service

Any defect in materials or workmanship in the product occurring within 12 months from the original date of purchase will be rectified free of charge by Philips Service or one of our authorised service centers.

Conditions of warranty

- All claims for warranty service should be made to your nearest Philips Service Branch or to a Philips authorised service dealer. Reasonable evidence of date of purchase must be provided.
- This warranty extends only to defects occurring under normal use of the product when operated in accordance with the instructions.
- Home service within the normal service area of Philips Service or one of our authorised service centres will be provided for television receivers with screen size 59cm and above. All other products are to be brought or sent to your nearest Philips Service Branch or to an authorised service centre.
- This warranty does not cover:

- Mileage or traveling time, pickup or delivery, cost of insurance.
- Service costs arising from failure to correctly adjust the controls of the product or to observe the instructions, or inspections that reveal that the product is in normal working order.
- Product failures caused by misuse, neglect, normal wear and tear, accidental breakage, transit damage, inexpert repairs or modification by unauthorised persons, lightning strikes, vermin instestation or liquid spillage.
- Cleaning of video or audio heads.
- Inadequate receiving antennae.
- Replacement of worn or used batteries, styli or other consumables.

The conditions contained in this warranty replace and override the provisions of the World-Wide Guarantee for Products sold in Australia.

Philips Service Branches

To contact your nearest Philips Service Branch call **1300 36 3392** from anywhere in Australia.

Sydney

Technology Park
Australia Centre
3 Figgite Drive
Homebush NSW 2140

Newcastle & Central Coast

984 Hunter Street
Newcastle West NSW 2302

Perth

1 Fredrick Street
Belmont WA 6104

Melbourne

Cnr Wellington &
Springvale Roads
Mulgrave VIC 3170

Brisbane

10 Graystone Street
Tingalpa QLD 4173

Also Service Centres:

Adelaide

348 Torrens Road

Croydon Park SA 5008

Hobart

2A Pierce Street
Moonah TAS 700

Wollongong

1/216 Corrimal Street
Wollongong NSW 2500

Canberra

Unit F,
66-70 Maryborough Street
Fyshwick ACT 2609

Service is also provided through 1,200 accredited service dealers throughout Australia. To find out about your nearest centre, call **1300 36 3392**.

Call us direct on the Philips Customer Helpline

Philips customer care lasts as long as you keep the product. Whenever you need any information on the care or operation of your product, remember it's always best to go straight to the source. Phone Philips Helpline direct on

1300 36 3391
7 days a week

– your call is always welcome.

Please record the following information for your records and keep in a safe place.

Model No:.....

Serial No:.....

Please retain your purchase receipt which is required to claim service under warranty.

Philips Electronics Australia Limited
ACN 008 445 743, 3 Figgite Drive
Homebush NSW 2140

Version 2, 08/97, FCCP–030

NEW ZEALAND Guarantee and Service for New Zealand

Thank-you for purchasing this quality Philips product. Philips New Zealand Ltd guarantees this product against defective components and faulty workmanship for a period of 12 months. Any defect in materials or workmanship occurring within 12 months from the date of purchase subject to the following conditions will be rectified free of charge by the retailer from whom this product was purchased.

Conditions

- The product must have been purchased in New Zealand. As proof of purchase, retain the original sales docket indicating the date of purchase.
- The guarantee applies only to faults caused by defective components, or faulty workmanship on the part of the manufacturer.
- The guarantee does not cover failures caused by misuse, neglect, normal wear and tear, accidental breakage, use on the incorrect voltage, use contrary to operating instructions, or unauthorised modification to the product or repair by an unauthorised technician.
- Reasonable evidence (in the form of a sales docket) must be supplied to indicate that the product was purchased no more than 12 months prior to the date of your claim.
- In the event of a failure, Philips shall be under no liability for any injury, or any loss or damage caused to property or products other than the product under guarantee.

This guarantee does not prejudice your rights under common law and statute, and is in addition to the normal responsibilities of the retailer and Philips.

How to claim

Should your Philips product fail within the guarantee period, please return it to the retailer from whom it was purchased. In most cases the retailer will be able to satisfactorily repair or replace the product.

However, should the retailer not be able to conclude the matter satisfactorily, or if you have other diffi-culties claiming under this guarantee, please contact **The Guarantee Controller**
Philips New Zealand Ltd.
P.O. Box 41.021

Auckland
☎ (09) 84 94 160
fax 📠 (09) 84 97 858

English

POLIZA DE GARANTÍA

ESTA POLIZA ES GRATUITA

Este aparato ha sido cuidadosamente diseñado y se ha fabricado con los mejores materiales bajo un estricto control de calidad, garantizando su buen funcionamiento por los periodos establecidos según el aparato (ver lista en la parte inferior) **a partir de la entrega del aparato al consumidor. Esta póliza incluye la reparación o reposición gratuita de cualquier parte o componente que eventualmente fallase y la mano de obra necesaria para su reparación**, misma que se hará efectiva en cualquiera de nuestros centros de servicio autorizados en el país.

Si su aparato llegase a requerir de nuestro servicio de garantía, acuda al centro de servicio más cercano a su domicilio, de tener alguna duda por favor llame a nuestra central de servicio al tel.: 7284252, y en el interior del país LADA sin costo al 01 800 506 92 00 en donde con gusto le indicaremos el cetro de servicio autorizado más cercano a su domicilio.

PHILIPS MEXICANA S.A. de C.V. a través de sus centros de servicio autorizados **reparará y devolverá a usted su aparato en un plazo no mayor a 20 días hábiles**, contados a partir de la fecha de ingreso, impresa en la orden de servicio de cualquiera de nuestros centros de servicio autorizados.

La garantía de esta póliza cubre cualquier desperfecto o daño eventualmente ocasionado por los trabajos de reparación y/o traslado del aparato en el interior de nuestros centros de servicio autorizados.

Esta póliza sólo tendrá validez, si está debidamente requisitada, sellada y firmada por la casa vendedora, en caso de extravío de esta póliza, podrá hacer efectiva su garantía con la presentación de su factura de compra.

ESTA POLIZA NO SE HARÁ EFECTIVA EN LOS SIGUIENTES CASOS:

- Cuando el aparato sea utilizado en condiciones anormales y los daños o desperfectos que manifieste sean causados por mal trato, descuido o mal uso.

- Cuando el aparato no haya sido operado de acuerdo a su instructivo de uso, en donde se señalan las condiciones normales de operación, los valores nominales y las tolerancias de las tensiones (voltaje), frecuencia (ciclaje) de alimentación eléctrica y las características que deben reunir las instalaciones auxiliares.

- Cuando la causa de la falla o mal funcionamiento sea consecuencia de una reparación inadecuada o alteración producida por personas no autorizadas por PHILIPS MEXICANA S.A. de C.V.

- Cuando los datos de esta póliza hayan sido alterados o modificados.

- Por fenómenos naturales no imputables a la empresa tales como: temblores, inundaciones, incendios, descargas eléctricas, rayos, etc.

PERIODOS DE GARANTÍA

12 MESES. – Televisores, videocaseteras, proyectores, cámaras de video, decodificadores de señal (IRD), T.V. hotel, sistemas de observación, televisores de proyección, teléfonos celulares, pagers, equipos modulares, sintonificadores.

6 MESES. – Radio grabadoras con y sin compact disc, mini reproductores de cassette, reproductor de CD portátil, radio relojes, radios A.M.F.M., auto estéreos, teléfonos inalámbricos.

3 MESES. – Accesorios, controles remotos y bocinas.

Philips Mexicana, S.A. de C.V.

<i>Producto importado por:</i> Philips Mexicana, S.A. de C.V. Norte 45 No. 669 Col. Ind. Vallejo Del. Azcapotzalco C.P. 02300 Tels. 72842 00 y 72948 00	<i>Centro de Información al Consumidor:</i> Norte 45 No. 669 Col. Ind. Vallejo Del. Azcapotzalco C.P. 02300 Tels. 368 77 88 Lada 01 800 504 62 00	<i>Centro de Servicio Vallejo:</i> Norte 45 No. 669 Col. Ind. Vallejo Del. Azcapotzalco C.P. 02300 Tel. 368 20 33
---	--	--

En caso que en su producto se produzca alguna falla, acuda al centro de servicio más cercano a su domicilio (según listado de talleres), de tener alguna duda, por favor llame a nuestra CENTRAL DE SERVICIO, en donde con gusto le atenderemos.

Asimismo cuando requiera refacciones y partes originales para su producto, acuda a los mismos centros de servicio. Para hacer efectiva la garantía de su producto, es necesario que presente usted esta póliza debidamente requisitada o de lo contrario presentar su factura de compra.

Modelo _____ **N° de Serie** _____ La presente garantía contará a partir de: _____ día _____ mes _____ año

Ciudad	EDO	Calle y N°	Colonia	C. P.	Nombre Comercial	Lada	Telefono	Fax
Acapulco	GRD	Av. Revolution N° 28	M. Aleman	39300	Servicio Electronico Profesional	74	83 32 96	--
Cd. Juarez	CHIH.	Rancho el Becerro 3011	Pradera Dora	39300	Teleservicio Dominguez	16	18 21 28	18 21 28
Cd. Reynosa	TAMPS	Rosalinda Guerrero Esq. 5 de Febrero	Prof. Longoria	88699	Centro de Servicio Lugo	892	492 43	--
Chihuahua	CHIH.	Trasviña y Retes N° 3503-A	San Felipe	31240	Zener Electronica	14	14 01 16	26 50 41
Colima	CDL	Francisco I. Madero N° 426	Centro	28000	TV Antenas de Colim	331	403 01	403 01
Culiacan	SIN.	Venustiano Carranza N° 140-A Nte.	Centro	80090	Estereo Voz	67	16 15 10	--
Guadalajara	JAL	Av. Vallarta N° 2250	Ladron de Guevara	44600	Leecom S.A. de C.V.	3	616 18 88 616 01 26	615 72 62
Leon	GTO	Hernandez Alvarez N° 726	Ssan Juan de Dios	37480	Tecnicos Especializados	47	47 70 26-99	15 58 64
Merida	YUC	Calle 70 N° 443 X 49 Depto. 8	Centro	97000	Servicentro	99	28 54 28	23 39 97
Mexicali	B.C.N.	Calz. Cuauhtemoc N° 866-2	Cuauhtemoc Nte.	21200	Baja Electronic's	619	67 49 16	67 49 16
Mexico	D.F.	Norte 45 N° 669	Industrial Vallejo	2300	Philips Mexicana S.A. de C.V.	5	368 20 33	728 42 72
Mexico	D.F.	Calz. Vallejo N° 804 Loc. 5	Industrial Vallejo	2300	Tecnologia y Servicio S.A. de C. V.	5	587 57 99	587 57 99
Mexico	D.F.	Pilares N° 519 Local C-3	Del Valle	03100	Cocesionario Pilares	5	605 42 15 605 42 67	605 43 46
Monterrey	N.L.	Juan Mendez N° 825 Nte.	Centro	64000	Monterrey Centro Electronico S.A.	8	375 16 17	374 85 42
Morelia	MICH.	Lago de Patzcuaro N°500-A	Ventura Puente	58020	Multiserv. Prof. de Zamora	43	12 03 17	--
Oaxaca	OAX	Huazares N° 207	Centro	68000	El Francisor. S. de R.L. de C.V.	951	647 37	--
Pachuca	HGO	Pza. de las Americas Lote 28 Nucleo D	Valle de Sn Javier	42086	Frazare Electronica	77	14 15 81	--
Puebla	PUE	Av. 10 Poniente N° 2902-B	San Alejandro	72090	Concesionario Philips de Puebla	22	30 34 39	--
Queretaro	QRO	Bolivia 32	Lomas de Queretaro	76190	Electronica Zener	421	610 09	--
San Luis Potosi	S.L.P.	Fuente De La Gloriaeta N° 147	Balcones del Valle	78320	Servicios Electronicos	481	534 07	--
Tampico	TAMPS	Laredo N° 105	Mainero	89060	Concesionario Philips Tampico	12	12 36 04	--
Tijuana	B.C.N.	Calle 1a. N° 1540-3	Centro	22000	Sistemas Inalambricos de Comunicacion	66	85 95 58	85 95 58
Toluca	EDO MEX	alle Toluca N° 505	Sanchez	50040	Concesionario Philips Toluca	72	14 83 09	17 03 21
Torreón	COAH	Mariano Lopez Ortiz N° 1126 Nte.	Centro	27000	Electronica Jomar	17	22 00 05	--
Tuxtla Gutierrez	CHIS	10 Nte. Ote 153-A	Centro	29000	KC-Video	96	18 19 08	--
Veracruz	VER	Av. Costa Verde N° 1116	Fracc. Costa Verde	94294	Servicios Esp. en Electronica	29	21 07 02	21 07 02
Villahermosa	TAB	Sanchez Marmol N° 206	Centro	88000	Tecnicentro	93	14 31 36	--



Let's make things better.

PHILIPS

AE 6775 - Portable Radio


English

Français

Español

中文

Meet PHILIPS at the internet <http://www.philips.com>
 inted in Hong Kong TC text/RB/9852



POWER/BAND PRESET 1-5 TUNING ▲▼

DISPLAY

DYNAMIC BASS BOOST

PHILIPS

AE6775 AM/FM STEREO RECEIVER

TIME SET LOCK battery compartment

RESET

9/10K

VOLUME

DBB

AAA/R03/UM4 1.5V x 2

México **NOM**

Es necesario que lea cuidadosamente su instructivo de manejo.

	PRECAUCIÓN - ADVERTENCIA No abrir, riesgo de choque eléctrico ATENCIÓN Verifique que el voltaje de alimentación sea el requerido para su aparato	
Para evitar el riesgo de choque eléctrico, no quite la tapa. En caso de requerir servicio, diríjase al personal calificado.		

Descripción (*Description*): **Reproductor de Cassette**

Estereofónico

Modelo (*Model*): **AE 6780/01**

Alimentación (*Mains*): **n/a**

Consumo (*Consumption*): **n/a**

mportador (*Importer*): **Philips Mexicana, S.A. de C.V.**

Domicilio (*Street*): **Norte 45, # 669, Col. Industrial Vallejo**

ocalidad y Telefono (*City and Phone*): **C.P. 02300 México D.F., Tel. 28 4200**

xportador (*Exporter*): **Philips Hongkong, Ltd.**

aís de Origen (*Origin*): **China**

Nº de Serie (*Serial number*): _____

LEA CUIDADOSAMENTE ESTE INSTRUCTIVO ANTES DE USAR SU APARATO.