

Register your product and get support at
www.philips.com/welcome

QUICK START



Thanks for buying **Philips AJL308** clock radio.
Our **Quick Start** guides you through just some of the features on the set.
Please read our instruction booklet to really rise & shine!

PHILIPS

English

I. Connecting power

- Connect the supplied mains adapter to the set's 9V DC jack and the plug into a wall outlet.

II. Setting time and date

1. Press **MENU**.
2. Use ◀▶ to highlight "Clock".
3. Use ▲▼ to select a field of "Time Set" and "Date (Year-Month-Day)".
4. Press **OK** to confirm.
5. Press or hold down ▲▼ to set the values.
6. Press **OK** to confirm.
7. Repeat Steps 3-6 to set other values of "Time Set and "Date (Year-Month-Day)".
8. After finishing the setting, press **CLOCK**, **TUNER**, **PHOTO/VIDEO** or **MUSIC** to exit the setup menu.

Helpful hint:

In the clock mode, to zoom the picture displayed, press and hold **CLOCK** for around 2 seconds, then press **OK** repeatedly to enlarge picture or resume to normal size, and use ◀▶▲▼ to pan the enlarged picture through. To exit the zoom mode, press **CLOCK** again.

Before zoom



After zoom



III. Setting/Activating alarm time

You can set two different alarm times.

1. Press **CLOCK**.
2. Hold down **ALARM 1** or **ALARM 2** for about 2 seconds, then release.
3. Press or hold down ▲▼ to set hour.
4. Press **ALARM 1** or **ALARM 2** to confirm.
5. Press or hold down ▲▼ to set minute.
6. Press **ALARM 1** or **ALARM 2** to confirm.
7. Press again **ALARM 1** or **ALARM 2** to activate alarm setting.
→ When alarm is activated, 📞 displays.

IV. Switching off the alarm


- During alarm call, press any button except **REPEAT ALARM / BRIGHTNESS CONTROL**.
→ Alarm will auto reset daily.

OR

- Press **REPEAT ALARM / BRIGHTNESS CONTROL** to enable repeat alarm in 9 minutes.
- To switch off alarm completely, press **ALARM 1** or **ALARM 2** repeatedly until 📞 is changed to 📞.
→ When alarm is deactivated, 📞 displays. When it is activated, 📞 displays.

Helpful hint:

- During alarm call, if no button is pressed, alarm call will last 30 minutes.
- To set the alarm sound with specific music, select desired music in the "Alarm Music" of the Clock menu.



V. Tuner

1. Press **TUNER**.
2. Press **MENU**.
→ The Tuner menu appears.
3. Press ▼ to select "Tuner Auto Program".
4. Press **OK** to start the auto search and programming.
→ 20 available stations are programmed (FM).
5. Press ▲▼ once or more to select your desired station.
- In **TUNER** mode, to turn off radio, press **OK**. To turn on radio, press **OK** again.
- To auto tune to a radio station, press and hold press and hold ◀▶ for about 2 seconds, then release. (To store particular station, refer to "Manual programming" of Tuner section in the user manual.)


VI. Using USB device or SD/MMC

To listen to music or view photo or video, you need to connect a USB device and/or memory card to AJL308.

1. Plug a compatible USB device and/or memory card (SD or MMC card) to USB port and/or card slot of AJL308.
→ The folder(s) indicating the inserted device(s) appears.
2. Press **▲ ▼** to select the folder of USB device (if present) or memory card (if present).
3. Press **OK** to open the folder:
→ **The set will auto switch to clock mode.**
 - To switch to music mode, press **MUSIC**.
 - To switch to photo mode, press **PHOTO/VIDEO**.
 - To switch to video mode, press **PHOTO/VIDEO**.
4. Select the file you want to play.
5. Press **OK** to play.

Helpful hint:

- The set supports DivX and MPEG4 video format.
- You may change still picture display format on the screen by selecting "Widescreen" or "Normal" under "Display Format" option in the "General" menu.



VII. Setting sleep

- In **TUNER** or **MUSIC** mode, press **SLEEP** until your desired sleep option is displayed.
→ The current **Tuner** or **Music** playback will continue.
- OR,**
- In **CLOCK** or **PHOTO/VIDEO** mode, press **SLEEP** until your desired sleep option is displayed.
→ The built-in relaxation music will start playback.

Helpful hint:

- There are several built-in relaxation music, select your desired one in the "Sleep Timer Music" option of the "General" menu.

VIII. Brightness control

- Press **REPEAT ALARM / BRIGHTNESS CONTROL** repeatedly to cycle screen brightness through 4 levels.

IX. Screen auto dim

- To avoid strong light emitting from the unit at night time, the auto dim function can be used to adjust the brightness to the lowest level automatically.
- To turn on auto dim, in the General menu, set On in "Auto Dim Timer", then set desired start time in "Auto Dim Start", and set desired end time in "Auto Dim End".
→ During auto dim time span, press any button to increase screen brightness, and it will last for 10 seconds.

X. Using the stand

The set is equipped with a stand on the bottom panel. To set the unit for a different viewing angle, take the stand out, then place it back by reversing (see the figure below) the side of the stand.

