

D 2010 Koninklijke Philips Electronics N.V. All rights reserved.

Specifications are subject to change without notice.

Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

Printed in China DC320\_98\_QSG\_V1.0



Register your product and get support at www.philips.com/welcome



### Quick start guide

- 1 Connect
- 2 Setup
- 3 Enjoy

Docking Entertainment System
DC320


### What's in the box



## 1 Connect



- 1 Prepare the AC power adaptor.
- 2 Connect one end of the AC adaptor to the **DC IN** socket on the main unit
- **3** Connect the other end of the AC adaptor to the wall outlet.







# Setup

### A Set time and date

- 1 In standby mode, press and hold **SET** TIME/PROG for 2 seconds.
- → [12 HR] begins to blink.
- 2 Press | ◀◀/▶▶| to select 12/24 hour format.
- 3 Press SET TIME/PROG to confirm. → The hour digits begin to blink.
- 4 Press | to set the hour.
- 5 Press SET TIME/PROG to confirm. → The minute digits begin to blink.
- 6 Repeat steps 4-5 to set the minute, year, month, and day.

### B Set the alarm timer

You can set two alarms which go off at different time.

1 Ensure that you have set the clock correctly.

- 2 Press and hold ALM 1 or ALM 2 for 2 seconds.
  - → [AL 1] or [AL 2] begin to
- 3 Press SOURCE to select an alarm sound source: iPod/iPhone, iPod/ iPhone playlist, FM tuner, or buzzer.
- 4 Press ALM 1 or ALM 2.
- → Hour digits begin to blink.
- 5 Press | ◀◀/▶▶ repeatedly to set the hour.
- 6 Press ALM 1 or ALM 2 to confirm.
- → Minute digits begin to blink.
- 7 Repeat steps 5-6 to set the minute.
- 8 Repeat steps 5-6 to select whether to ring alarm the whole week. on weekdays, or at weekend.
- **9** Repeat steps 5-6 to set the alarm volume.

## 2 Setup

#### Activate and deactivate the alarm timer

- 1 Press ALM 1 or ALM 2 repeatedly to activate or deactivate the timer.
- → If the timer is activated, [ ♣ AL 1] or [ AL2] is displayed.
- → If the timer is deactivated, [ AL1] or [ AL2] disappears.

#### Repeat alarm

- 1 When the alarm rings, press **BRIGHTNESS/REP ALM.**
- → The alarm repeats ringing minutes later.

#### (3) Tip

 You can press |◄◄/▶▶| to adjust the interval to repeat alarm.


#### Stop alarm ring

- 1 When the alarm rings, press the corresponding ALM 1 or ALM 2.
- → The alarm stops but the alarm settings remain.

## Enjoy

### A Play from iPod/iPhone

1 Place the iPod/iPhone in the dock.



- 2 Press SOURCE repeatedly to select iPod/iPhone source.
- → The connected iPod/iPhone plays automatically.
- To pause/resume play, press ►II
- To skip to a track, press I◄ **/**▶▶|.

### 3 Enjoy

- To search during play, press and hold I◀◀/▶▶I. then release to resume normal play.
- To go back to previous iPod/ iPhone menu, press **MENU**. To scroll through the menu, press **PRESET +/-**. To confirm a selection, press OK/►II.
  - → If no key is pressed for more than 10 seconds. OK/►II acts back as the play/pause key.

#### B Program and listen to radio stations

- 1 In the tuner mode, press and hold SET TIME/PROG for more than 2 seconds to activate automatic program mode.
- → All available stations are programmed in the order of waveband reception strength.
- → The first programmed radio station is broadcast automatically.
- 2 Press PRESET +/- to select a preset number.



 Detailed functions and features are described in the user manual.