








# 1



# 2



# 3

AL 1 / AL 2 2 sec.

PRESET +  
PRESET -

AL 1 / AL 2

PRESET +  
PRESET -

AL 1 / AL 2

PHILIPS

The diagram shows a sequence of steps to set an alarm. It starts with a Philips remote control. The first step is to press the 'AL 1' or 'AL 2' button for 2 seconds. This is followed by pressing the 'PRESET +' or 'PRESET -' buttons. The second step is to press 'AL 1' or 'AL 2' again. This is followed by another press of 'PRESET +' or 'PRESET -'. The final step is to press 'AL 1' or 'AL 2' a third time. The remote control has buttons for POWER, MENU, SLEEP, PRESET +, PRESET -, OK, TUNING -, TUNING +, FM, DAB, MP3 LINK, DOCK, AUTO SCAN, BRIGHTNESS, SET TIME, REP AL, INFO, DBB, DSC, + VOL, - VOL, AL 1, and AL 2.

# 4

IPHONE

DOCK

The diagram shows an iPhone being placed into the dock of a car stereo. A blue arrow points to the dock slot. The car stereo has a display showing 'IPHONE' and a button labeled 'DOCK'.

MP3-LINK

The diagram shows an MP3 player connected to the car stereo via an MP3-LINK cable. The cable is plugged into the MP3-LINK port on the car stereo. The car stereo has a display and several buttons.

# 5

DAB+

DAB

1

2

3

2 sec.

AUTO SCAN  
SET TIME

PRESET +  
PRESET -

The diagram shows the car stereo set to DAB mode. The display shows 'DAB+'. A blue circle highlights the 'DAB' button on the remote control. A blue circle highlights the 'AUTO SCAN' button on the remote control. A blue circle highlights the 'PRESET +' and 'PRESET -' buttons on the remote control. The steps are numbered 1, 2, and 3. Step 1 is pressing the 'DAB' button. Step 2 is pressing the 'AUTO SCAN' button for 2 seconds. Step 3 is pressing the 'PRESET +' or 'PRESET -' buttons.

FM

1

2

3

2 sec.

AUTO SCAN  
SET TIME

PRESET +  
PRESET -

The diagram shows the car stereo set to FM mode. The display shows 'FM-TUNER'. A blue circle highlights the 'FM' button on the remote control. A blue circle highlights the 'AUTO SCAN' button on the remote control. A blue circle highlights the 'PRESET +' and 'PRESET -' buttons on the remote control. The steps are numbered 1, 2, and 3. Step 1 is pressing the 'FM' button. Step 2 is pressing the 'AUTO SCAN' button for 2 seconds. Step 3 is pressing the 'PRESET +' or 'PRESET -' buttons.

