



HR8339

- 1 V Use manual
- 2 BC Nivelação automática
- 3 BC Nivelação automática
- 4 BC Nivelação automática
- 5 BC Nivelação automática
- 6 BC Nivelação automática
- 7 BC Nivelação automática
- 8 BC Nivelação automática
- 9 BC Nivelação automática
- 10 BC Nivelação automática
- 11 BC Nivelação automática
- 12 BC Nivelação automática
- 13 BC Nivelação automática
- 14 BC Nivelação automática
- 15 BC Nivelação automática
- 16 BC Nivelação automática
- 17 BC Nivelação automática
- 18 BC Nivelação automática

PHILIPS

- 1 When the appliance is powered on it auto automatically and continuously dispenses providing additional heat and reducing the risk of overheating.
- 2 When the straightening plates have heated up to the selected temperature the indicator READY* (3) is displayed.
- 3 Note: If the bottom is present the hair ends behind the straightener in the display on the LCD screen. To deactivate the lock function, slide and hold the key-lock button (4) for 1.5 seconds.
- 4 To avoid unintentional switching of buttons during process, you can activate the key-lock function manually by sliding and holding the key-lock button (4) for 1.5 seconds.
- 5 Note: The appliance will auto shut-off if function After use is engaged with 2 hair care technologies working together. Temperature technology. Thanks to a high-performance motor the straightener keeps a more constant temperature which allows you to straighten hair up to 180°C and therefore more caring temperature just below 200°C while getting the style you want.
- 6 Philips EHD-Technology™ - The entire plates always distribute the heat evenly which prevents damaging hot spots.

Specifications are subject to change without notice

© Philips 2017. Philips is a registered trademark of Philips N.V. All rights reserved.

English

1 Introduction

Congratulations on your purchase, and welcome to the Philips fully benefit from the support that Philips offers, register your product at [www.philips.com/welcome](#).

The Philips CareTemp Straightener has newly developed Dual Care™ plates that ensure your hair is protected from too high heat and ensure the assurance of the best result. The Dual Care™ plates are equipped with 2 hair care technologies working together: Temperature Technology™. Thanks to a high-performance motor the straightener keeps a more constant temperature which allows you to straighten hair up to 180°C and therefore more caring temperature just below 200°C while getting the style you want.

Philips EHD-Technology™ - The entire plates always distribute the heat evenly which prevents damaging hot spots.

2 Important

- 1 Read this user manual carefully before you use the appliance and keep it for future reference.
- 2 **WARNING! Do not use this appliance near water.**
- 3 When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk, even when the appliance is switched off.
- 4 **WARNING! Do not use this appliance near bathtubs, showers, basins or other vessels containing water.**
- 5 Always unplug the appliance after use.
- 6 If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.
- 7 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 8 Before you connect the appliance, ensure that the voltage indicated on the appliance corresponds to the local power voltage.
- 9 Do not use the appliance for any other purpose than described in this manual.
- 10 When the appliance is connected to the power, never leave it unattended.
- 11 Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- 12 Do not wind the mains cord round the appliance.
- 13 Wait until the appliance has cooled down before you store it.
- 14 Pay full attention when using the appliance since it could be extremely hot. Only hold the handle as other parts are extremely hot.
- 15 Always place the appliance with the stand on a heat-resistant, stable flat surface. The hot heating plates should never touch the surface or other flammable material.
- 16 Avoid the mains cord from coming into contact with the hot parts of the appliance.
- 17 Keep the appliance away from flammable objects and material when it is switched on.
- 18 Never cover the appliance with anything (e.g. a towel or clothing) when it is hot.
- 19 Only use the appliance on dry hair. Do not operate the appliance with wet hands.
- 20 Keep the heating plates clean and free of dust and styling products such as mousse, spray and gel. Never use the appliance in combination with styling products.
- 21 The heating plates has coating. This coating might slowly wear away over time. However, this does not affect the performance of the appliance.
- 22 If the appliance is used on color-treated hair, the heating plates will not affect the color.
- 23 Always consult the appliance to a service centre authorized by Philips for examination or repair. Repair by unqualified people could result in an extremely hazardous situation for the user.
- 24 Do not insert metal objects into openings to avoid electric shock.

Electromagnetic fields (EMF)

This Philips appliance complies with applicable standards and regulations regarding exposure to electromagnetic fields.

Environment

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Please do not dispose of your product as general waste. Philips is a member of the Green Group, a group of companies that make products that are safe for the environment.

3 Straighten your hair

- 1 Connect the plug to a power supply socket.
- 2 Press the power button (1) to turn the LCD screen light up.
- 3 The default temperature is displayed on the LCD screen (2).
- 4 Press the ready button (3) to display, indicating the function is automatically generated, with only a selected to protect your hair.
- 5 Press the stop button (4) to stop the straightening for the first time.

4 Guarantee and service

You need information or advice about replacement of an attachment or if you have a problem please visit the Philips website at [www.philips.com/welcome](#) or contact the Philips Customer Care Centre in your country. The phone number is in the worldwide guide for your local Philips dealer.

5 Troubleshooting

Problem	Cause	Solution
Power button does not work	The power socket is not connected.	Ensure the socket is live.
Key lock button does not work	The appliance which the appliance is not plugged in or the LCD screen is switched off.	Disconnect the key lock function by sliding and holding the key lock button for 1.5 seconds.
Power cord is damaged	The main cord of the appliance must be replaced by Philips, a service centre authorized by Philips or similarly qualified persons in order to avoid a hazard.	Discontinue the key lock function by sliding and holding the key lock button for 1.5 seconds.

Общ преглед на пресата за изпращане на коса

1 Введение

Поздравяваме ви за покупката и ще ви помолим да се регистрирате на [www.philips.com/welcome](#) за да получите всички от промишления от Филипс разработени инструменти за изпращане на коса. Продуктът е оборудван с 2 технологии за грижа за косата, работещи заедно: Технологията за температура. Благодарение на мощния мотор косата се изпраща при по-стабилна температура, което ви позволява да правите по-бавно и по-полека косата си до температура от 180°C, а след това да я изпращате до температура от 200°C, докато получите желания стил, който искате.

2 Важно

- 1 Прочетете внимателно инструкциите за употреба на продукта и запазете си този документ за бъдеща употреба.
- 2 **ВНИМАНИЕ!** Не използвайте уреда близо до вода.
- 3 **ВНИМАНИЕ!** Не използвайте уреда близо до ванни, душове, мивки или съдове с вода.
- 4 **ВНИМАНИЕ!** Не използвайте уреда близо до водни, душове, мивки или съдове с вода.
- 5 **ВНИМАНИЕ!** Не използвайте уреда близо до водни, душове, мивки или съдове с вода.
- 6 С едма употреба винаги изключвайте уреда от контакта.
- 7 С едма предотвратяване на опасност, при повредена захранваща кабел той трябва да бъде сменен от Филипс, отговарящ от Филипс сервис или квалифициран техник.
- 8 Този уред може да се използва от деца на възраст над 8 години и от хора с намалени физически възможности или умствени недостатъци или без помощта на повърхността, ако са инструктирани за безопасна употреба на уреда и са под наблюдение с цел гарантиране на безопасна употреба и ако си им различни евентуални опасности. Не позволявайте на деца да си играят с уреда. Не позволявайте на деца да извършват почистване или поддръжка на уреда без надзор.
- 9 Преди да включите уреда в контакта, проверете дали посоченото върху уредна напрежение отговаря на това на местната електрическа мрежа.
- 10 Не използвайте уреда за цели, различни от указаното в това ръководство.
- 11 Никога не оставяйте уреда без надзор, когато е включен в електрическата мрежа.
- 12 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 13 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 14 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 15 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 16 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 17 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 18 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 19 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 20 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 21 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 22 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 23 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.
- 24 Никога не използвайте аксесоари или части от други производители или части от други производители или части от други производители или части от други производители.

Electromagnetic fields (EMF)

This Philips appliance complies with applicable standards and regulations regarding exposure to electromagnetic fields.

Environment

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Please do not dispose of your product as general waste. Philips is a member of the Green Group, a group of companies that make products that are safe for the environment.

3 Straighten your hair


- 1 Connect the plug to a power supply socket.
- 2 Press the power button (1) to turn the LCD screen light up.
- 3 The default temperature is displayed on the LCD screen (2).
- 4 Press the ready button (3) to display, indicating the function is automatically generated, with only a selected to protect your hair.
- 5 Press the stop button (4) to stop the straightening for the first time.

4 Guarantee and service

You need information or advice about replacement of an attachment or if you have a problem please visit the Philips website at [www.philips.com/welcome](#) or contact the Philips Customer Care Centre in your country. The phone number is in the worldwide guide for your local Philips dealer.

5 Troubleshooting

Problem	Cause	Solution
Power button does not work	The power socket is not connected.	Ensure the socket is live.
Key lock button does not work	The appliance which the appliance is not plugged in or the LCD screen is switched off.	Disconnect the key lock function by sliding and holding the key lock button for 1.5 seconds.
Power cord is damaged	The main cord of the appliance must be replaced by Philips, a service centre authorized by Philips or similarly qualified persons in order to avoid a hazard.	Discontinue the key lock function by sliding and holding the key lock button for 1.5 seconds.



HR8339

- 1 V Use manual
- 2 BC Nivelação automática
- 3 BC Nivelação automática
- 4 BC Nivelação automática
- 5 BC Nivelação automática
- 6 BC Nivelação automática
- 7 BC Nivelação automática
- 8 BC Nivelação automática
- 9 BC Nivelação automática
- 10 BC Nivelação automática
- 11 BC Nivelação automática
- 12 BC Nivelação automática
- 13 BC Nivelação automática
- 14 BC Nivelação automática
- 15 BC Nivelação automática
- 16 BC Nivelação automática
- 17 BC Nivelação automática
- 18 BC Nivelação automática

PHILIPS

- 1 When the appliance is powered on it auto automatically and continuously dispenses providing additional heat and reducing the risk of overheating.
- 2 When the straightening plates have heated up to the selected temperature the indicator READY* (3) is displayed.
- 3 Note: If the bottom is present the hair ends behind the straightener in the display on the LCD screen. To deactivate the lock function, slide and hold the key-lock button (4) for 1.5 seconds.
- 4 To avoid unintentional switching of buttons during process, you can activate the key-lock function manually by sliding and holding the key-lock button (4) for 1.5 seconds.
- 5 Note: The appliance will auto shut-off if function After use is engaged with 2 hair care technologies working together. Temperature technology. Thanks to a high-performance motor the straightener keeps a more constant temperature which allows you to straighten hair up to 180°C and therefore more caring temperature just below 200°C while getting the style you want.
- 6 Philips EHD-Technology™ - The entire plates always distribute the heat evenly which prevents damaging hot spots.

Specifications are subject to change without notice

© Philips 2017. Philips is a registered trademark of Philips N.V. All rights reserved.

English

1 Introduction

Congratulations on your purchase, and welcome to the Philips fully benefit from the support that Philips offers, register your product at [www.philips.com/welcome](#).

The Philips CareTemp Straightener has newly developed Dual Care™ plates that ensure your hair is protected from too high heat and ensure the assurance of the best result. The Dual Care™ plates are equipped with 2 hair care technologies working together: Temperature Technology™. Thanks to a high-performance motor the straightener keeps a more constant temperature which allows you to straighten hair up to 180°C and therefore more caring temperature just below 200°C while getting the style you want.

Philips EHD-Technology™ - The entire plates always distribute the heat evenly which prevents damaging hot spots.

2 Important

- 1 Read this user manual carefully before you use the appliance and keep it for future reference.
- 2 **WARNING! Do not use this appliance near water.**
- 3 When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk, even when the appliance is switched off.
- 4 **WARNING! Do not use this appliance near bathtubs, showers, basins or other vessels containing water.**
- 5 Always unplug the appliance after use.
- 6 If the mains cord is damaged, you must have it replaced by Philips, a service centre authorized by Philips or similarly qualified persons in order to avoid a hazard.
- 7 This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 8 Before you connect the appliance, ensure that the voltage indicated on the appliance corresponds to the local power voltage.
- 9 Do not use the appliance for any other purpose than described in this manual.
- 10 When the appliance is connected to the power, never leave it unattended.
- 11 Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- 12 Do not wind the mains cord round the appliance.
- 13 Wait until the appliance has cooled down before you store it.
- 14 Pay full attention when using the appliance since it could be extremely hot. Only hold the handle as other parts are extremely hot.
- 15 Always place the appliance with the stand on a heat-resistant, stable flat surface. The hot heating plates should never touch the surface or other flammable material.
- 16 Avoid the mains cord from coming into contact with the hot parts of the appliance.
- 17 Keep the appliance away from flammable objects and material when it is switched on.
- 18 Never cover the appliance with anything (e.g. a towel or clothing) when it is hot.
- 19 Only use the appliance on dry hair. Do not operate the appliance with wet hands.
- 20 Keep the heating plates clean and free of dust and styling products such as mousse, spray and gel. Never use the appliance in combination with styling products.
- 21 The heating plates has coating. This coating might slowly wear away over time. However, this does not affect the performance of the appliance.
- 22 If the appliance is used on color-treated hair, the heating plates will not affect the color.
- 23 Always consult the appliance to a service centre authorized by Philips for examination or repair. Repair by unqualified people could result in an extremely hazardous situation for the user.
- 24 Do not insert metal objects into openings to avoid electric shock.

Electromagnetic fields (EMF)

This Philips appliance complies with applicable standards and regulations regarding exposure to electromagnetic fields.

Environment

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Please do not dispose of your product as general waste. Philips is a member of the Green Group, a group of companies that make products that are safe for the environment.

3 Straighten your hair

- 1 Connect the plug to a power supply socket.
- 2 Press the power button (1) to turn the LCD screen light up.
- 3 The default temperature is displayed on the LCD screen (2).
- 4 Press the ready button (3) to display, indicating the function is automatically generated, with only a selected to protect your hair.
- 5 Press the stop button (4) to stop the straightening for the first time.

4 Guarantee and service

You need information or advice about replacement of an attachment or if you have a problem please visit the Philips website at [www.philips.com/welcome](#) or contact the Philips Customer Care Centre in your country. The phone number is in the worldwide guide for your local Philips dealer.

5 Troubleshooting

Problem	Cause	Solution
Power button does not work	The power socket is not connected.	Ensure the socket is live.
Key lock button does not work	The appliance which the appliance is not plugged in or the LCD screen is switched off.	Disconnect the key lock function by sliding and holding the key lock button for 1.5 seconds.
Power cord is damaged	The main cord of the appliance must be replaced by Philips, a service centre authorized by Philips or similarly qualified persons in order to avoid a hazard.	Discontinue the key lock function by sliding and holding the key lock button for 1.5 seconds.

Това обаче не влияе на работата на уреда.

• Ако уредът се използва върху боюдисана коса, пластините може да станат на петна. Преди да използвате уреда върху изкуствена коса, непременно се консултирайте с дистрибутора на косата.

• За проверка или ремонт носете уреда само в установения от Филипс сервиз. Ремонт, извършен от неавтентични лица, може да създаде изключително опасни ситуации за потребителя.

• За да избегнете токов удар, не пхквайте метални предмети в отворите.

Електромагнитни излъчвания (EMF)

This Philips appliance complies with applicable standards and regulations regarding exposure to electromagnetic fields.

Environment

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Please do not dispose of your product as general waste. Philips is a member of the Green Group, a group of companies that make products that are safe for the environment.

3 Изпращане на косата

- 1 Connect the plug to a power supply socket.
- 2 Press the power button (1) to turn the LCD screen light up.
- 3 The default temperature is displayed on the LCD screen (2).
- 4 Press the ready button (3) to display, indicating the function is automatically generated, with only a selected to protect your hair.
- 5 Press the stop button (4) to stop the straightening for the first time.

4 Guarantee and service

You need information or advice about replacement of an attachment or if you have a problem please visit the Philips website at [www.philips.com/welcome](#) or contact the Philips Customer Care Centre in your country. The phone number is in the worldwide guide for your local Philips dealer.

5 Troubleshooting

Problem	Cause	Solution
Power button does not work	The power socket is not connected.	Ensure the socket is live.
Key lock button does not work	The appliance which the appliance is not plugged in or the LCD screen is switched off.	Disconnect the key lock function by sliding and holding the key lock button for 1.5 seconds.
Power cord is damaged	The main cord of the appliance must be replaced by Philips, a service centre authorized by Philips or similarly qualified persons in order to avoid a hazard.	Discontinue the key lock function by sliding and holding the key lock button for 1.5 seconds.

• Забраňte tomu, aby se horké díry přístroje dotýkaly napřejeho kabelu.

• Je-li přístroj zapnutý, uchovávejte jej mimo dosah hoflavých předmětů a materiálů.

• Je-li přístroj horký, nikdy jej nejm nezakrývte (např. rukavicemi nebo oblečením).

• Přístroj používejte pouze na suché vlasy. Nepoužívejte přístroj, pokud máte mokré vlasy.

• Ohřívací destičky udržujte čistě, bez prachu a kadeřnických přípravků, jako jsou olejové, tukové, spreje, gely. Přístroj nepoužívejte v kombinaci s kadeřnickými přípravky.

• Ohřívací destičky mají upravený povrch. Tento povrch se může postupně pomalu odtrhnout. Tento je však normální věš, vlasy na výkon přístroje. Pokud přístroj používáte na barvené vlasy, ohřívací destičky se mohou uspřnit. Před jejich použitím na umělé vlasy se poradte s jejich distributorem.

• Kontrolu nebo opravu přístroje svěřte vždy servisu společnosti Philips.

• Opravy provedené nekalifikovanými osobami mohou být pro uživatele mimořádně nebezpečné.

• Nevkładkujte kovové předměty do otvorů. Předčete tak úrazu elektrickým proudem.

Electromagnetic fields (EMF)

This Philips appliance complies with applicable standards and regulations regarding exposure to electromagnetic fields.

Environment

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Please do not dispose of your product as general waste. Philips is a member of the Green Group, a group of companies that make products that are safe for the environment.

3 Изпращане на косата

- 1 Connect the plug to a power supply socket.
- 2 Press the power button (1) to turn the LCD screen light up.
- 3 The default temperature is displayed on the LCD screen (2).
- 4 Press the ready button (3) to display, indicating the function is automatically generated, with only a selected to protect your hair.
- 5 Press the stop button (4) to stop the straightening for the first time.

4 Guarantee and service

You need information or advice about replacement of an attachment or if you have a problem please visit the Philips website at [www.philips.com/welcome](#) or contact the Philips Customer Care Centre in your country. The phone number is in the worldwide guide for your local Philips dealer.

5 Troubleshooting

Problem	Cause	Solution
Power button does not work	The power socket is not connected.	Ensure the socket is live.
Key lock button does not work	The appliance which the appliance is not plugged in or the LCD screen is switched off.	Disconnect the key lock function by sliding and holding the key lock button for 1.5 seconds.
Power cord is damaged	The main cord of the appliance must be replaced by Philips, a service centre authorized by Philips or similarly qualified persons in order to avoid a hazard.	Discontinue the key lock function by sliding and holding the key lock button for 1.5 seconds.

• Asetage seade koos alusega alati kuumaineldale stabielse tasasele kuumale. Kuumaid sirgendusplaaid ei tohi kunagi panna ega muude tuleohutlike materijaledega kokku puutuda.

• Ärge laske tootejuhtmel vastu seadme kuumi osi minna.

• Hoidke sisselülitatud seadet kergeti süttivast ettekäetised ja materijaleid ära puudutades, eriti kui need on niisked.

• Kuni ärge laske kuumale seadmel millegi külmi (nt käterätid või riietüki).

• Rakendage seadet ainult kuivadele juustele. Ärge kasutage seadet niisketele juustele.

• Hoidke sirgendusplaate puhtana ning ärge laske neile tolm, prahi ega juuksehooldusvahendite, nagu juukseväga, pesuvahendite ja geeli jääke koguneda. Ärge kasutage seadme seadete koos juuksehooldusvahenditega.

• Sirgenduspilaidet on ka te. See kaite võib plaka ja jooksul ära kuluda. Sama ei mõjuta kuumade seadme jõudlust.

• Kui seadet kasutate vedu juustel, siis võivad sirgendusplaadid märduda. Enne kasutamist kunstjuustepõhisele alale nende eesmisilma pooli.

• Viise seade toote osimiseks või parandamiseks alati Philipsi volitatud teeninduskuskesse. Kui seadet parandab kvalifitseerimata isik, võib see seada kasutaja vähe ohtlikku olukorda.

• Elektrilöögi ärahoidmiseks ärge sisetage vähe sisetage seadmesse materiale.

Electromagnetic fields (EMF)

This Philips appliance complies with applicable standards and regulations regarding exposure to electromagnetic fields.

Environment

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Please do not dispose of your product as general waste. Philips is a member of the Green Group, a group of companies that make products that are safe for the environment.

3 Изпращане на косата

- 1 Connect the plug to a power supply socket.
- 2 Press the power button (1) to turn the LCD screen light up.
- 3 The default temperature is displayed on the LCD screen (2).
- 4 Press the ready button (3) to display, indicating the function is automatically generated, with only a selected to protect your hair.
- 5 Press the stop button (4) to stop the straightening for the first time.

4 Guarantee and service

You need information or advice about replacement of an attachment or if you have a problem please visit the Philips website at [www.philips.com/welcome](#) or contact the Philips Customer Care Centre in your country. The phone number is in the worldwide guide for your local Philips dealer.

5 Troubleshooting

Problem	Cause	Solution
Power button does not work	The power socket is not connected.	Ensure the socket is live.
Key lock button does not work	The appliance which the appliance is not plugged in or the LCD screen is switched off.	Disconnect the key lock function by sliding and holding the key lock button for 1.5 seconds.
Power cord is damaged	The main cord of the appliance must be replaced by Philips, a service centre authorized by Philips or similarly qualified persons in order to avoid a hazard.	Discontinue the key lock function by sliding and holding the key lock button for 1.5 seconds.

• Prije pohrane pričekaite da se aparat ohladi.

• Budite vrlo pažljivi prilikom korištenja aparata jer on može biti izuzetno vruć. Aparat držite samo za dršku jer su drugi dijelovi vrući te izbjegavajte kontakt s kožom.

• Aparat uvijek postavljajte s postojem na stabilnu i ravnu površinu otpornu na zapaljenje. Ne držite gačice ploče ne smiju biti u dodiku s drugim ili drugim zapaljivim materijalom.

• Izbjegavajte dodir mrežnog kabela s vrhušom dijelovima aparata.

• Kad je uključen, aparat držite podalje od zapaljivih stvari i materijala.

• Dok je vruć, aparat nikada nemojte pokrivati rukavicima ili tkaninom.

• Aparat koristite isključivo na suhoj kosi. S aparatom nemojte raditi ako su vam kose mokre.

• Grijačice potrebaju biti očistene od prljavštine, prašine i sredstava za oblikovanje frizure poput pjene, lak i gela. Aparat nikada nemojte koristiti u kombinaciji s proizvodima za oblikovanje.

• Grijačice potrebaju imati premaz. Za obloga s vremenom se može polako trošiti. Medutim, to ne utječe na rad aparata.

• Ako aparat koristite na obojanoj kosi, na grijanim pločama mogu ostati mirisi. Prije upotrebe na umjetnoj kosi, obavezno se posavjetujte s nejinim distributorom.

• Aparat uvijek dostavite u ovlaštenoj Philips servisi centar na ispitivanje ili popravak. Popravak od strane nestručnih osoba može rezultirati izuzetno opasnom situacijom za korisnika.

• Nemojte umetati metalne predmete u otvore kako biste izbjegli opasnost od strujnog udara.

Electromagnetic fields (EMF)

This Philips appliance complies with applicable standards and regulations regarding exposure to electromagnetic fields.

Environment

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

Please do not dispose of your product as general waste. Philips is a member of the Green Group, a group of companies that make products that are safe for the environment.

3 Изпращане на косата

- 1 Connect the plug to a power supply socket.
- 2 Press the power button (1) to turn the LCD screen light up.
- 3 The default temperature is displayed on the LCD screen (2).
- 4 Press the ready button (3) to display, indicating the function is automatically generated, with only a selected to protect your hair.
- 5 Press the stop button (4) to stop the straightening for the first time.

4 Guarantee and service

You need information or advice about replacement of an attachment or if you have a problem please visit the Philips website at [www.philips.com/welcome](#) or contact the Philips Customer Care Centre in your country. The phone number is in the worldwide guide for your local Philips dealer.

5 Troubleshooting

Problem	Cause	Solution
Power button does not work	The power socket is not connected.	Ensure the socket is live.
Key lock button does not work	The appliance which	

