


Quick start guide


2 Enjoy

1 Prepare (for in-car use)

- 1 Attach the main unit and the second screen to the back of the front seat headrests.




- 2 Connect the supplied AV cable to the **AV OUT** jack on the main unit and the **AV IN** jack on the second screen.
- 3 Connect the supplied car adaptor cable to the **DC IN** jacks on the main unit and the second screen, and to the car cigarette lighter socket.




1 Prepare (for domestic use)

Connect additional equipment (TV for example)

- 1 Connect the **AV OUT** socket on the main unit to the video and audio sockets on a TV as shown directly.
- 2 Connect the AC adaptor cable to the **DC IN** Jack on the main unit and the power outlet.



- 3 Switch on the TV and set to the correct video-in channel.
 - You can consult the owner's manual of your TV. (If your TV does not have Audio and Video inputs, you will need to purchase a RF modulator. Please consult your dealer.)



- 1 Slide the **ON/OFF** switch to **ON** to switch on the main unit.
- 2 Slide **OPEN ►** on the main unit.
- 3 Remove the protective card (if any) and load a disc with the label side facing up.
- 4 Close the disc compartment.
 - Playback will start automatically. If not, press **►/OK**.
- 5 To stop playback, press **■**.

Note:

During play, you can:

- Press **OPTION** to select some play options: audio, subtitle, repeat, and time display.
- Press **BRIGHTNESS** on the main unit or rotate **BRIGHTNESS -/+** on the second screen to adjust brightness of screen to match lighting conditions.

